

Load Cell Central
1-800-LOADCEL

410/422

Weight Indicator

Installation/Calibration/Operation

version 1.a
08/25/01



Load Cell Central follows a policy of continuous improvement and reserves the right to change specifications without notice. © 2011

Load Cell Central
216 Main St. / PO Box 91
Monroeton, PA 18832
Web: www.800loadcel.com

Toll Free: 1-800-562-3235
Ph: 1-570-265-5015
Fax: 1-570-265-5148
Email: sales@800loadcel.com

INTRODUCTION 4

Organization of Manual	4
Warranty Information	5

GENERAL DESCRIPTION 6

The 410/422 Display and Keyboard Diagram	6
The 410/422 Display	6
The 410/422 Keyboard	7

INSTALLATION AND SETUP 8

Unpacking the 410/422	8
Installation Guide	8
Setup Guide	10
NTEP Labeling Instructions	12

USING THE 410/422 13

Keyboard Layout	13
Select Mode of Operation (Parameter73)	13
Modes of Operation	14
Normal Mode (Mode 0)	14
Keyboard Tare (Mode 1)	15
Print Weight and Total (Mode 2)	16
Print Weight with Subtotal and Total (Mode 3)	17
Multi-Container/Axle Weighing (Mode 4)	17
Auto Weigh and Print (Auto Axle weigh) (Mode 5)	18
Auto Axle Weigh (Long Scale) (Mode 6)	19
Peak Hold (Mode 7)	19
Over / Under Check Weigh (Mode 8)	20
Bulkweigh (Mode 9)	20

SET OPERATION PARAMETERS 22

Access Operation Parameters and Parameter Functions	22
Operation Parameter Reference Tables	22
Scale Parameters	23
Parameter 1. Load Cell m/V (3 m/V)	25
Parameter 2. Digital Filter (9)	25
Parameter 3. Display Update Rate (0)	26
Parameter 4. Motion Detection Delay (15)	26

Parameter 5. Motion Detection Band (6)	26
Parameter 6. Enable Display Blanking During Motion (no blanking)	26
Parameter 7. Zero tracking Delay (1)	26
Parameter 8. Zero Tracking Band (12)	26
Parameter 9. Push Button Zero Percent (100)	27
Parameter 10. Primary Units Type (1[lb])	27
Parameter 11. Decimal Point Position (0[no decimal point])	27
Parameter 12. Count-By (1)	27
Parameter 13. Alternate Units Type (2[kg])	28
Parameter 14. Alternate Decimal Point (1)	28
Parameter 15. Alternate Count-By (5)	28
Parameter 16. Alternate Units Conversion Factor (45,360)	28
Parameter 17. Full Scale Graduations (10,000)	29
Parameter 18. Overload Graduations (10,200)	29
Parameter 19. Deadload Offset (automatically set)	29
Parameter 20. Disable Power-on Zero (1[power-on zero disabled])	29
Parameter 21. Deadload Factor (automatically set)	29
Parameter 22. Weight Conversion Factor (automatically set)	29
Serial I/O Ports	30
Parameter 23. Serial Port 1 Mode (4[8 data bits, no parity])	30
Parameter 24. Serial Port 1 Baud Rate (1[9600 baud])	30
Parameter 25. Serial Port 2 Mode (4[8 data bits, no parity])	31
Parameter 26. Serial Port 2 Baud Rate (1[9600 baud])	31
Parameter 27. TX2 Control / Station ID (255[single station])	31
Parameter 28. TX2 Format (2[Condec data format])	32
Printer Parameters	33
Parameter 30. Auto Line Feed after Carriage return (1[yes])	33
Parameter 31. End of Print Character (12[form feed])	33
Parameters 32, 33, 34, 84, 85, 86 and 87. Print Labels	33
Parameters 35, 36, 37 and 38. Print Codes	34
Parameter 39. TTL Remote Control (1[ttl in = scale basic function])	34
Display Intensity, Watch Dog Timer	34
Parameter 40. Display intensity (10)	34
Parameter 41. Battery Enable (0[optional clock needed])	34
Parameter 42. Enable Watch Dog Timer (0)	34
Parameter 43-50. Fixed Registers	34
Parameters 51-56. Keyboard Event Functions	35

PARAMETER FUNCTIONS 36

Function 59. Display Calibration Audit Number	37
Function 60. Calibrate Scale (deadload first)	37
Function 61. Calibrate Scale (span first)	38
Function 62. Calibrate (deadload only)	38
Function 63. Adjust Gain Calibration	38
Function 64. Configure Passwords	39
Function 65. Configure Print Formats	39
Function 66. Configure Time and Date	43
Function 67. Display Operation Parameters	43
Function 68. Print Operation Parameters	43
Function 69. Diagnostic Tests	43
Function 70. Initialize Operation Parameters to Factory Default	44
Function 71. Configure Event monitor	44
Function 72. Scale Basic Function Editor	48
Function 73. Select Mode of Operations	48
Function 74. Configure Timers	49
Function 76. Debug Mode	49
Function 78. Initialize ID Memory	49
Function 79. Enable Multi-point Linearization	49
Function 80. Multi-point Linearization Calibration	49

TROUBLE SHOOTING 50

ERROR MESSAGES	51
-----------------------	-----------

HARDWARE INSTALLATION AND WIRING 52

Load Cell Connector–TB1	52
Power Supply AC/DC connections	52
I/O Port Connectors and Digital port – TB3/TB4	52
P.C. Board Diagram–Connectors, Jumpers, and switches	53
0-10 VDC/4-20mA Analog Output (option)	54
ASCII II Chart	55
Specifications	56

INTRODUCTION

Congratulations on your purchase and welcome to the 410/422 User's Manual. This manual describes the installation and operation of the 410/422 weight indicator. The Load Cell Central 410/422/422 is a microprocessor based weight indicator with rugged design and state-of-the-art technology. It is designed for use in industrial environments to perform the following functions:

- *Analog to Digital conversion (A/D)* - converts the analog signal from a strain gauge "load cell" to a numeric weight.
- *Signal Processing* - filters electrical and mechanical noise from the load cell signal using electronic circuits and digital filtering.
- *Basic Weighing* - push button zero, tare functions (push button and keyboard tare), display of gross or net weight and scale status, and transmission of weight data to a printer and a computer.
- *Additional Functions* - there are 10 modes of operation: basic weighing, print & total, print & subtotal & total, manual axle weigh, automatic axle weigh, automatic axle weigh - long scale, over/under checkweigh, and bulkweighing.

The 410/422 has two bi-directional serial communication ports that are used for printer output, bar code input, computer communications, and remote control. The serial ports support RS232, RS422, RS485, and 20ma Current Loop communication. The 410/422 Digital port has 3 TTL outputs and 3 TTL inputs.

ORGANIZATION

This manual is divided into separate sections which describe the installation, calibration, setup, operation, and testing of the 410/422. The installation, calibration, and setup sections are intended for trained scale technicians familiar with the installation of weighing instrumentation.. The other sections present information applicable to a user, installer, or system integrator. Please note that this is not a service manual and the unit is not user-serviceable. All service work must be performed by qualified technicians.

WARRANTY INFORMATION

LOAD CELL CENTRAL LIMITED WARRANTY.

Load Cell Central, warrants that the products furnished are free from defects in material and workmanship and perform to applicable, published Load Cell Central, specifications for one (1) year from the date of shipment.

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY EXPRESSED OR IMPLIED. IN NO EVENT SHALL LOAD CELL CENTRAL. BE LIABLE FOR LOSS OF PROFITS, OR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES, OR FOR OTHER SIMILAR DAMAGES ARISING OUT OF ANY BREACH OF THIS WARRANTY PROVISION.

The liability of Load Cell Central shall be limited to repairing or replacing, WITHOUT CHARGE, any defective products which are F.O.B Load Cell Central. Plant. Equipment or parts which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair or installation are not covered by warranty. Load Cell Central shall have the right of final determination as to the existence and cause of defect. As to items repaired or replaced, the warranty shall continue in effect for the remainder of the warranty period, or for ninety (90) days following date of shipment by Load Cell Central of the repaired or replaced product, whichever period is longer. No liability is assumed for expendable items such as lamps and fuses. No warranty is made with respect to customer equipment or products produced, to Buyer's specifications except as specifically stated in writing by Load Cell Central and contained in the contract. In no case is product to be returned without first obtaining permission and a Customer Return Authorization Number (RMA) from Load Cell Central. Product being returned during or after the original warranty period should be carefully packed and sent prepaid and insured along with an explanation of the problem. Customer shall be responsible for all damages resulting from improper packaging or handling, and for loss in transit. If it is found that Load Cell Central product has been returned without cause and is still serviceable, customer will be notified and Product returned at customer's expense. Repairs or replacements made by Load Cell Central on Products under warranty will be returned, shipped at NO CHARGE by method of shipment Load Cell Central deems most advantageous.

EXCEPT AS SPECIFICALLY PROVIDED HEREIN, THERE ARE NO OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

RETURN POLICY

Any piece of equipment purchased by the original purchaser can only be returned for credit or exchange during the first 45 days after shipment. This policy excludes any returns for warranty consideration. Items returned for other than warranty is subject to a restock fee equal to 25% of the list price of the hardware. This fee is assessed for packaging, handling, testing, inspection, and the resultant paperwork that is required to receive and return the hardware to stock for resale.


All such items should be returned in its original shipping container. Any damage not reported when the purchaser originally received the hardware or software is also subject to reasonable repair fees to bring it back to new condition. The purchaser will be advised of these fees in writing at the time they are assessed.

All items returned should be returned with a Return Material Authorization number (RMA) issued by a LCC employee. The RMA number should be clearly marked on the outside of the box.

GENERAL DESCRIPTION

This section gives you a general description on the operation of the 410/422's keyboard and display. The keyboard is used to initiate weighing functions, for data entry, maintenance, setup, and testing. The numeric display is used for weight and error display and for data entry. The LED status lights indicate the status of the weigh scale.

410/422 Display and Keyboard Diagram



410/422 Display

The 410/422 DISPLAY consists of a 6 character NUMERIC display and 6 status LED's. The NUMERIC display is normally used to display the weight on the scale. The LED's display the scale status. When lighted they indicate the following conditions:

- GROSS- The number displayed is the gross weight on the scale.
- NET - The number displayed is the net weight on the scale.
- MOTION- The weight on the scale is changing (not stable).
- ZERO- The scale is at "Center of Zero".
- LB- The weight displayed is in increments of LB's.
- KG- The weight displayed is in increments of KG's.

The 410/422 Keyboard

The keyboard is used to initiate weighing functions and for setup of the 410/422.

Function Keys

The function keys ZERO, TARE, GROSS/NET, UNITS and PRINT are used to Zero the scale, Tare the scale, switch the weight display between Gross and Net display, switch the weight display between LB and KG display, and Print the weight. The key function may be changed when the mode of operation is changed or configured by the user. The operation of the function keys is explained in chapter 4, titled "USING THE 410/422".

Alternate Function Keys

The data entry procedure has been enhanced for the setup mode and other data entry related procedures. The new user interface is much easier and more intuitive. Negative numbers and decimal points may now be entered for some register parameters (setpoints) and during the test weight entry in the calibration mode.

The following steps describe how to use the alternate function keys for data entry in the configure mode or any data entry function:

1. Press and hold the GROSS/NET key down and then press the UNITS key. The unit enters configure mode and displays "CFG xx", where "xx" is the current parameter selected.
2. The alternate function keys (ITEM, +, -, ENTER) are used to select any parameter and change the current numeric value.
3. Press the ITEM key to select the digit to change. The first digit (most significant digit) is selected and begins flashing to indicate the current selection. To select another digit, press the ITEM key repeatedly until the desired digit is selected.
4. After you select the digit to change, use the (+) or (-) keys to increment or decrement the selected digit. Once the digit has been changed, use the ITEM key to select another digit and repeat this procedure. Note: The minus sign '-' can only be selected on the first digit.
5. Press the ENTER key to accept the current value or press the CLEAR key to discard any changes.

INSTALLATION AND SETUP

This section provides information about unpacking, installing, and setup of the 410/422. It also directs the installer to the appropriate sections of the manual for hardware and setup installation.

Unpacking the 410/422

Installation begins with unpacking the 410/422. Observe any instructions or cautions which appear in the shipping container. Check the items in the shipping container against the following item check list or the packing list. LCC will not accept responsibility for shortages against the packing list unless notified within 30 days. All equipment and accessories are inspected and tested by LCC before shipment. Inspect the equipment carefully. If shipping damage is evident, notify the carrier immediately. Take photographs if necessary. You are responsible for final claim and negotiations with the carrier. Save the packing and shipping container in case you need to store, return, or transport the 410/422 for any reason.

Item check list

- (1) 410/422 - Weight Indicator w/power cord.
- (1) This User's Manual.
- (2) Capacity labels and (2) transparent overlays.
- (1) A sheet that describes the capacity label placement.
- (1) Package of fasteners for the 410/422 back panel.

NOTE: The container may include additional items that have been purchased separately.

Installation Guide

WARNING!! Do not apply power to the unit until all connections are completed as described in this section and the access panel has replaced and secured onto the back of the 410/422.

Connect 410/422 to load cell or junction box

Connect the load cell or junction box to the Load Cell Terminal Block (TB1) located inside 410/422's enclosure. See the HARDWARE INSTALLATION AND WIRING section (page 8-1) for pin assignments and a sample cable drawing.

Connect 410/422 to the printer (optional)

The 410/422 can be connected to a printer using Com Port 1 (TB3) for RS232 or Current Loop interfaces. See the HARDWARE INSTALLATION AND WIRING section (page 8-2) for pin assignments and sample cable drawings.

Connect 410/422 to host device (optional)

The Serial Communications Port 2 (TB3) provides a continuous output of scale data. This is used for connection to a host device such as a computer or to a remote display (scoreboard). Continuous output transmission can be enabled or disabled and the

output format can be customized to interface with the host device (see OPERATIONS PARAMETERS - Continuous TX2 Format, page 5-10). See the HARDWARE INSTALLATION AND WIRING section (page 8-2) for pin assignments and sample cable drawings.

Apply AC/DC Power to the 410/422

Once you have connected the 410/422 to the load cell and optional equipment, plug the power cord into AC or DC power.

The 410/422 has an onboard transformer for AC applications. Insert the power cord into the AC socket-outlet and the unit will power up, the plug on the power supply cord is considered the units disconnect device. The socket-outlet shall be installed near the equipment and shall be easily accessible.

For DC applications the motherboard is equipped with a 2 position terminal block marked "PWR-DC" connect the positive source side to the terminal marked + and negative to the terminal marked -. See the HARDWARE INSTALLATION AND WIRING section (page 8-1) for pin assignments and a sample cable drawing.

On power-up, the 410/422 performs the following tests:

- 1 *A/D Conversion Test* - the 410/422 checks the A/D converter to verify that data conversions are taking place.
- 2 *Keyboard Scan* - the keyboard is scanned to verify that no keys are engaged..
- 3 *Memory Test* - the 410/422 displays "rtESt" while it performs a memory test on internal memory. If a problem is encountered during the test, an error message is displayed.
- 4 *Lamp Test* - all segments on the numeric display and all LED's are turned on for 5 seconds.
- 5 *Conversion Display* - the IDS 410/422 displays "Ad xxx", where "xxx" is the conversion count. This test takes approximately 10 seconds.
- 6 *Stability Check* - the 410/422 displays "Cxxxx" where "xxxx" is the raw data difference in load cell readings. The 410/422 waits until the data difference is within a stable range. To exit the above power on test functions, press the **clear** [ZERO] key. This is possible only if the 410/422 has not been locked. The 410/422 is now ready for initialization, calibration, and configuration.

Setup Guide

Setup the 410/422 in the following order:

Initialize to Factory Defaults

The 410/422 is initialized at the factory. It must be re-initialized if the program memory (EPROM, U4 , RAM U5), the parameter memory (EAROM, U12) is replaced or if the optional clock chip in being installed for the first time. The Initialize function clears the memory and sets the configuration parameters to their default values. Use parameter function 70 initialize system. When the display prompts "rESEt0" enter **10809** code as described in chapter 6 to initialize the 410/422.

NOTE: Configuration and calibration and must be performed after the 410/422 is initialized

Setup & "Quick" Calibration Guide

Set the configuration parameters BEFORE calibration. Chapter 5: **SET OPERATION PARAMETERS** details the parameters that are available for configuration. To quickly get the 410/422 up and running, the following Quick Calibration Guide lists only the mandatory parameters that must be defined.

The parameters are accessed by holding the GROSS/NET key down and then pressing the UNITS key. The numeric display prompts "CFG xx", where xx is the currently selected parameter. The alternate functions (**clear, item, +, -, enter**) of the keyboard are now active. Press the **item** key to select a digit, press the (+) key to advance the CFG number by 1, and press the (-) key to decrement the CFG number by 1. Press the **enter** key to begin configuration of the displayed parameter number.

Parameter	Purpose (Factory Setting)
CFG 1	Load Cell mv/V (3)
CFG 11	Decimal Point (0 [none])
CFG 12	Count-by (1)
CFG 17	Full Scale Graduations (10,000)
CFG 18	Overload Graduations (10,200)
CFG 73	Select Mode of Operation

NOTE: Read the first section of chapter 5: **Access Operation Parameters** for detailed instructions on how to access and set the parameters.

Calibrate the Weight Indicator


Use Parameter Function (CFG 60 or 80) to calibrate the weight indicator (page 6-2). Parameter 80 is used for mutipoint linerization. **Note:** Parameter 79 must be set to a 1 to enable multipoint calibration before entering into parameter 80.

NTEP LABELING INSTRUCTIONS

Labeling Guidelines For NTEP Applications

These guidelines pertain to the use of the 410/422 in NTEP (National Type Evaluation Program) applications. If you are unfamiliar with NTEP, it is probable that this information can be disregarded for your application.

NTEP has implications for “Legal-For-Trade” requirements only. These requirements generally pertain to weighing scales that must be certified as accurate by local, state and federal Weights and Measures officials.



For installations that are to be certified as “Legal-For-Trade”, install the NTEP label approximately as shown.

The label consists of two parts, the label and the backing material. Carefully remove the backing from the label and affix the label to the 410/422 in the position indicated above.


Label text must be inserted by the user/installer in the space provided to reflect the scale/weighing system capacity and minimum display increment (count-by). A permanent ink marking pen or matte-finish vinyl lettering is recommended for this purpose. After the appropriate information is in place, apply one of the supplied transparent overlays to protect the complete label.

Using the 410/422

The 410/422 weigh scale indicator has 10 modes of operation. See chapter 5 "Set Operation Parameters", configuration parameter 73 to select one of the modes.

Keyboard Layout

The 410/422 has 5 function keys that are used for weighing functions, data entry, parameter setup, and testing. The setup functions are described in chapter 5 "Set Operation Parameters", the test functions are described in chapter 7 "Diagnostic Tests". The weighing functions and data entry functions of the keyboard are determined by the mode that is currently selected.



Select Mode of Operation

Access the configuration parameters by holding the GROSS/NET key down and then pressing the UNITS key. The numeric display prompts "CFG xx", where xx is the currently selected parameter. Use the alternate key functions to select a parameter. Press the **enter** key to begin parameter data entry.

Parameter data entry uses the alternate keyboard functions (**clear**, **item**, **+**, **-**, **enter**). To enter/change numeric data, use the **item** key to select a digit to change. The blinking digit is the currently selected digit. Use the (+) and (-) keys to increase or decrease the selected digit. Press the **enter** key to accept the displayed number, press the **clear** key to discard the changes.

Press the (+) or (-) key until the second from the right most digit is 7. Press the **item** key to advance to the next digit. Press the (+) or (-) key until the digit is 3 (display = 73). Press the **enter** key. Press the (+) or (-) keys to change the mode number. Press the ENTER key to store the displayed mode number. If you changed the mode number the display will prompt "rS Fnx" where 'x' is the new mode number. Press the **enter** key again. Some modes will prompt for additional information. (See descriptions below for details.) If you did NOT change the mode number then the "rS Fnx" message will NOT be displayed and the additional data will not be prompted for.

Press the **clear** key (when "CFG 73" is displayed) exit configuration setup.

Modes of Operation

Set configuration parameter (CFG 73) to one of the following modes:

- 0 - Normal
- 1 - Keyboard Tare
- 2 - Print weight and Total
- 3 - Print weight with Subtotal & Total
- 4 - Multi-Container/Axle Weighing
- 5 - Auto Weight and Print (Auto Axle Weigh)
- 6 -Auto-Axle Weigh (Long Scales)
- 7 - Peak Hold
- 8 - Over / Under Checkweigh
- 9 - Bulkweigh

Normal Mode (Mode 0)

The Normal Mode provides push button ZERO, push-button TARE, view GROSS/NET toggle, units (lb/kg) toggle, and print functions.

ZERO

Press the ZERO key to zero the scale. The following conditions must be met for the ZERO key to function:

- The gross weight is within the configured zero range: 1% to 100% of full scale.
- The scale is stable (no motion).

TARE

Press the TARE key. The 410/422 reads the weight on the scale and stores it in the tare register. The IDS 410/422 switches to NET mode and displays the net weight. If the gross weight on the scale is zero (0), the tare register is set to 0 and the mode switches to GROSS display mode.

Gross/Net

Press the Gross/Net key to alternate between Gross and Net display modes.

UNITS

Press the UNITS key to alternate between (lb) and (kg) display modes.

PRINT

Press the PRINT key to print weight data. Gross Weight (Page format 1) is printed if the 410/422 is in Gross display mode, Gross/Tare/Net (page format 2) are printed in the Net display mode.

Keyboard Tare (Mode 1)

The Keyboard Tare mode provides the ability to enter a tare weight using the keyboard.

ZERO

Press the ZERO key to zero the scale.

TARE

Press the TARE key. The 410/422 prompts "tArE". Enter the tare weight using the **item** key to select the digits to change. Use the (+) key to increase the selected digit or use the (-) key to decrease the selected digit. Press the **enter** key to store the displayed data into the tare register. The Load Cell Central 410/422 switches to NET mode and displays the net weight.

Gross/Net

Press the Gross/Net key to alternate between Gross and Net display modes.

UNITS

Press the UNITS key to alternate between (lb) and (kg) display modes.

PRINT

Press the PRINT key to print weight data. Gross Weight (Page format 1) is printed if the 410/422 is in Gross display mode, Gross/Tare/Net (page format 2) are printed in the Net display mode.

Print Weight and Total (Mode 2)

The Print Weight and Total mode provides a printout of numbered weighments with a running total.

PRINT

Press the PRINT key to print weight and running total data. The following example shows the printout from 3 PRINT commands when the weight meter is in the GROSS mode.

#	1	640 lb	TOTAL GROSS	640 lb
#	2	954 lb	TOTAL GROSS	1594 lb
#	3	325 lb	TOTAL GROSS	1919 lb

The next example shows the printout from 3 PRINT commands in the NET mode.

#	1	35 lb	TOTAL NET	35 lb
#	2	72 lb	TOTAL NET	107 lb
#	3	45 lb	TOTAL NET	152 lb

TOTAL (UNITS key)

The UNITS key is used for the TOTAL function. Press the UNITS key to print the final total and reset the total accumulator to 0.

The printout in the GROSS mode:

TOTAL GROSS	1919 lb
-------------	---------

The printout in the NET mode:

TOTAL GROSS	1919 lb
TOTAL TARE	1767 lb
TOTAL NET	152 lb

Print Weight with Subtotal and Total (Mode 3)

The Print Weight with Subtotal, and Total mode provides a subtotal register and a total register.

PRINT

Press the PRINT key to print weight data and totalize to the gross, tare and net weights.

TOTAL (UNITS key)

The UNITS key is used for the SUBTOTAL and TOTAL functions. Press the UNITS key to print the subtotal. Press the UNITS key 2 times to print the total and reset the total accumulator to 0.

Multi-Container/Axle Weighing (Mode 4)

The Multi-Container/Axle Weighing mode uses the PRINT key and UNITS key to print and totalize axles. This application is also used in other applications where numbered print and total of gross weights is required.

PRINT

Press the PRINT key to print an axle. The following is a sample of the axle-weigh printout:
NOT LEGAL FOR TRADE

#	1	639 lb
#	2	954 lb
#	3	325 lb

TOTAL (UNITS key)

Press the TOTAL (UNITS) key to print the total of the axles that have been weighed.

Total	1918 lb
-------	---------

Auto Weigh and Print / Axle Weigh (Mode 5)

The Auto Weigh and Print mode is used for unattended, short scale, container, axle weighing applications. This mode uses the following resources:

- TTL output 1 - RED light output
- TTL output 2 - GREEN light output
- Fixed Register 43 - trip level register
- Timer 1 - delay time before red light is turned on
- Timer 2 - delay time before green light is turned on
- Timer 3 - delay time before total is printed
- PRINT key - prints total (over-rides the auto total print timer)

This mode prompts for additional information when mode number is entered in the configuration function. (See **Set Mode Of Operation** at beginning of this chapter.)

The display prompts "triP". Press the **enter** key. The current trip level weight (register 43) is displayed. Use the **item**, +, and - keys to change the trip level weight. Press the **enter** key to accept the displayed trip level weight.

The display prompts "t1 xx" where xx is the current red light delay time (timer 1). Use the **item**, +, and - keys to change the delay time. Press the **enter** key to accept the displayed delay time.

The display prompts "t2 xx" where xx is the current green light delay time (timer 2). Use the **item**, +, and - keys to change the delay time. Press the **enter** key to accept the displayed delay time.

The display prompts "t3 xx" where xx is the current total print delay time (timer 3). Use the **item**, +, and - keys to change the delay time. Press the **enter** key to accept the displayed delay time.

Auto axle weighing begins with the green light on. A weight greater than the trip level enters the scale. Timer 1 is activated. Timer 1 times out and the green light is turned off and the red light is turned on. When motion detect signals no motion, the weight on the scale is printed, the green light is turned on, red light off, and timer 2 is activated. The axle weigh program waits for the weight on the scale to change by the trip level amount. If the scale weight settles above the trip level amount, the weight indicator totalizes and prints. Timer 2 times out when no trip level activation occurs in the auto-total timeout time; the weight indicator prints the total of the previous weighments and zeros the totals register. The PRINT key can be used to print totals before timer 2 times out.

Automatic Axle Weigh - Long Scale (Mode 6)

The Automatic Axle Weigh mode is used for unattended, long scale, axle weighing applications. It operates the same as mode 5 except the weight on the scale is tared after each weighment.

This mode prompts for additional information when mode number is entered in the configuration function. (See **Set Mode Of Operation** at beginning of this chapter.)

The display prompts "triP". Press the **enter** key. The current trip level weight (register 43) is displayed. Use the **item**, +, and - keys to change the trip level weight. Press the **enter** key to accept the displayed trip level weight.

The display prompts "t1 xx" where xx is the current red light delay time (timer 1). Use the **item**, +, and - keys to change the delay time. Press the **enter** key to accept the displayed delay time.

The display prompts "t2 xx" where xx is the current total print delay time (timer 2). Use the **item**, +, and - keys to change the delay time. Press the **enter** key to accept the displayed delay time.

Peak Hold (Mode 7)

The Peak Hold mode maintains the peak weight detected by the weight indicator.

Display Peak Weight

Use the GROSS/NET key to scroll thru the display options as follows:

Initial mode:	Display gross weight.	Gross LED on.
First GROSS/NET press:	Display net weight.	Net LED on.
Next GROSS/NET press:	Display gross peak weight.	Gross LED flashing.
Next GROSS/NET press:	Display net peak weight.	Net LED flashing.
Next GROSS/NET press:	Display gross weight.	Gross LED on.
etc.		

Print Peak Weight

Press the PRINT key when the indicator is in the peak display mode..

Clear Peak Hold Register

Press the UNITS key to reset the peak hold register to 0.

Over / Under Checkweigh (Mode 8)

The Over/Under Checkweigh mode uses 3 TTL outputs to indicate scale weight under setpoint1, between setpoint 1 & setpoint 2, or over setpoint 3.

Fixed register 43 = Setpoint 1

Fixed register 44 = Setpoint 2

TTL output 1 = Under

TTL output 2 = Between

TTL output 3 = Over

NOTE: if setpoint 1 = setpoint 2 then TTL 1 = under setpoint, TTL 2 = over setpoint.

This mode prompts for additional information when mode number is entered in the configuration function. (See **Set Mode Of Operation** at beginning of this chapter.)

The display prompts "SP 1". Press the **enter** key. The current under weight setpoint (register 43) is displayed. Use the **item**, +, and - keys to change the setpoint weight. Press the **enter** key to accept the displayed setpoint weight.

The display prompts "SP 2". Press the **enter** key. The current over weight setpoint (register 43) is displayed. Use the **item**, +, and - keys to change the setpoint weight. Press the **enter** key to accept the displayed setpoint weight.

Bulkweigh (Mode 9)

The Bulkweigh mode is used for filling operations where a relay output is turned on until the weight on the scale reaches a setpoint. The following resources are used:

SP1 (Fixed register 43) - scale empty weight

SP2 (Fixed register 44) - target draft weight

SP3 (Fixed register 45) - scale overweight

Timer 1 - settle time

Press the UNITS key to START bulk weighing.

Press the PRINT key to print total and prompt for clear total.

Use TTL input 1 for remote START function.

Use TTL input 2 for remote STOP function.

Use TTL output 1 to activate the fill relay.

Error message 90 scale not empty

Error message 91 draft overweight

This mode prompts for additional information when mode number is entered in the configuration function. (See **Set Mode Of Operation** at beginning of this chapter.)

The display prompts "SP 1". Press the **enter** key. The current scale empty setpoint (register 43) is displayed. Use the **item**, **+**, and **-** keys to change the setpoint weight. Press the **enter** key to accept the displayed setpoint weight.

The display prompts "SP 2". Press the **enter** key. The current target weight setpoint (register 44) is displayed. Use the **item**, **+**, and **-** keys to change the setpoint weight. Press the **enter** key to accept the displayed setpoint weight.

The display prompts "SP 3". Press the **enter** key. The current scale overweight setpoint (register 45) is displayed. Use the **item**, **+**, and **-** keys to change the setpoint weight. Press the **enter** key to accept the displayed setpoint weight.

The display prompts "t1 xx" where xx is the current scale settle time (timer 1). Use the **item**, **+**, and **-** keys to change the settle time. Press the **enter** key to accept the displayed settle time.

Press the UNITS key to begin a bulkweigh cycle.

The weight indicator checks for scale empty. TTL 1 turns on and the weight indicator waits for the weight on the scale to reach the target weight. TTL 1 turns off, the indicator times out (Timer 1) adds the net weight to the totals register, and then prints the gross, tare, and net weights.

Press the PRINT key to print the total amount weighed. The indicator prompts "ErASE". Press the PRINT key to clear the total register or press the GROSS/NET key to retain the total.

SET OPERATION PARAMETERS

This section describes the operation parameters of the IDS 410/422.

Access Operation Parameters and Parameter Functions

The parameters are accessed by holding the GROSS/NET key down and then pressing the UNITS key. The numeric display prompts "CFG xx", where xx is the currently selected parameter. Use the alternate key functions to select a parameter. Press the **enter** key to begin parameter data entry. Press the **clear** key to exit configuration mode and store the parameter data into memory.

Parameter data entry uses the alternate keyboard functions (**clear, item, +, -, enter**). To enter/change numeric data, use the **item** key to select a digit to change. The blinking digit is the currently selected digit. Use the (+) and (-) keys to increase or decrease the selected digit. Press the **enter** key to accept the displayed number or press the **clear** key to discard the changes.

EXAMPLE: Set the full-scale graduations (parameter 17) to 5000 -
Hold the GROSS/NET key down and press the UNITS key. Press the **item** key to select the second digit from the right, press the (+ or -) until the digit is 1. Press the **item** key. Press the (+ or -) key until the far right digit is 7. Press the **enter** key. The display prompts "10000". Press the **item** key until the far left digit blinks. Press the (-) key 1 time to change the 1 to 0. Press the **item** key. Press the (+) key 5 times to change the 0 to 5. Press the **enter** key to exit parameter 17 data entry. Press the **clear** key to exit configuration mode and store the parameter data into memory.

Operation Parameters Reference Tables

The reference tables provide an overview of the operation parameters. The sections following the reference tables describe the setup parameters in detail and the procedures for modifying them. Use the 'Field Settings' column of the reference tables to document any changes to the setup parameters.

Reference Table column heading descriptions:

No.: Use this number to access the parameter to be modified. For example to modify the Digital Filter enter CFG 3.

Parameter Name: The name of the parameter.

Default Value: The value set at the factory. The Parameter Function "Initialize Operation Parameters to Factory Defaults" sets the parameter to this value.

Maximum Value: The maximum value for numeric parameters, the maximum number of characters for alphanumeric parameters.

Password Level: The IDS 410/422 has 3 password levels. Level 1 requires entering password-1 before accessing the parameter. Level 2 requires password-2. Level 3 requires password-2 and the Lock Switch to be in the unlocked position.

Scale Parameters

No.	Parameter Name	Default	Max Value	Pass	Field Setting
1	Loadcell mv/v	3	3	3	
2	Digital filter	9	18	3	
3	Display Update Rate	1	200	3	
4	Motion delay time	6	250	3	
5	Motion band	6	250	3	
6	Motion blanks display	0 (no)	1	3	
7	Zero tracking delay	0	250	3	
8	Zero tracking band	12	250	3	
9	Push button zero percent	100	100	3	
10	Primary units type	1 (lb)	6(oz)	3	
11	Decimal point position	0	4	3	
12	Count-by	1	100	3	
13	Alternate units type	2 (kg)	6(oz)	3	
14	Alt decimal point	1	4	3	
15	Alternate count-by	5	100	3	
16	Alt conversion factor	45,360		3	
17	Full Scale display digits	10,000	120,000	3	
18	Over Weight dd	10,200	120,200	3	
19	Deadload offset			3	
20	Disable Power-On Zero	1	1	3	

I/O PORT Parameters

No	Parameter Name	Default	Maximum	Pass	Field Setting
23	Serial port 1 mode	4(8N1)	6	2	
24	Serial port 1 baud rate	1(9600)	7	2	
25	Serial port 2 mode	4(8N1)	6	2	
26	Serial port 2 baud rate	1(9600)	7	2	
27	TX2 control / Station Id	255	255	1	
28	TX2 Data Format	2 (condec)	4	2	
30	Autoprint LF after CR	1 (yes)	1	2	
31	End Of Print character	13 return	255	2	
32	Print label 1		16 char	2	
33	Print label 2		16 char	2	
34	Print label 3		16 char	2	
35	Print code 1		3 codes	2	
36	Print code 2		3 codes	2	
37	Print code 3		3 codes	2	
38	Print code 4		3 codes	2	
39	TTL remote control	0 (NO)	1	2	

Display Intensity, Battery, Watch Dog Timer

No	Parameter Name	Default	Maximum	Pass	Field Setting
40	Display intensity	10	15	2	
41	Battery installed (CLOCK)	0 (no)	1	2	
42	Enable watch dog timer	1 (yes)	1	1	

Fixed Setpoints

No	Parameter Name	Default	Maximum	Pass	Field Setting
43	Fixed setpoint 1	0	999999	1	
44	Fixed setpoint 2	0	999999	1	
45	Fixed setpoint 3	0	999999	1	
46	Fixed setpoint 4	0	999999	1	
47	Fixed setpoint 5	0	999999	1	
48	Fixed setpoint 6	0	999999	1	
49	Fixed setpoint 7	0	999999	1	
50	Fixed setpoint 8	0	999999	1	

Keyboard Events

No	Parameter Name	Default	Maximum	Pass	Field Setting
51	Power on start function	0	255	2	
52	Print key function	136	255	2	
53	Units key function	127	255	2	
54	Gross/Net key function	128	255	2	
55	Tare key function	129	255	2	
56	Zero key function	130	255	2	

Parameter Functions

Fn. No	Function Name	Password Level
59	Display Calibration Audit Number	0
60	Calibrate Scale - deadload first	3
61	Calibrate Scale - span first	3
62	Calibrate Deadload Only	3
63	Adjust Gain Calibration	3
64	Configure Passwords	2
65	Configure Print Formats	2
66	Set Time and Date	2
67	Display Operation Parameters	0
68	Print Operation Parameters	0
69	Diagnostic Tests	0
70	Initialize Operation Parameters to factory defaults.	3
71	Configure Event Monitor	2
72	Function Editor	2
73	Select Mode of operation (0-10)	2
74	Configure timers	2
76	Single-step Scale Basic functions	2
78	Erase ID Memory	2
79	Enable Multi-point Linearization	2
80	Multi-point calibration function	2

Scale Parameters

The scale parameters configure IDS 410/422 for the weigh platform or load cell that it is connected to. The preceding table titled "SCALE PARAMETERS" lists the scale parameters and their factory settings. Use the "Field Setting" column to record any changes made to the factory default values.

Many of the following parameters are entered in terms of "graduations". The full-scale graduations can be found by dividing the full-scale weight by the count-by weight. For example, if the scale is configured for 500.00kg x 0.05kg, the full-scale graduations is $500.00/0.05 = 10,000$ graduations to full scale.

The numbers in parenthesis are the default factory settings.

Parameter 1: Load Cell mv/V (3 mv/v)

The IDS 410/422 can be used with load cell outputs of 1 mv/V, 2 mv/V, or 3 mv/V. Enter a 1, 2, or 3 for the load cell type used in your application. NOTE: there are 2 additional settings: 0 for high gain (0.5mv/v inputs) and 4 for low gain (6 mv/v inputs).

Parameter 2: Digital Filter (9)

The digital filter removes scale vibrations and other noise signals from the weight display. The filter range is between 0 and 18. A setting of 0 provides no filtering; a setting of 18 provides maximum filtering. The higher the filters number the longer the settle time of the weight display. For example:

Filter Setting	Settle Time
3	0.4 sec
6	0.8 sec
9	1.75 sec
12	3.5 sec
15	7.0 sec

Use the smallest filter setting that provides satisfactory display stability.

Parameter 3: Display Update Rate (0)

Enter the time between display updates (in tenths of a second). An update rate of 1 causes a 0.1 second delay between display updates, a rate of 200 causes a 20 second delay between updates. NOTE: motion detection is calculated using the weight values of the display rate. If the update rate is 50, the motion calculation is based on weight readings sampled at 0.5sec intervals.

Parameter 4: Motion Detection Delay (15)

Motion detection delay is used by the motion detection function to determine if the scale is in motion (not stable). Enter the amount of time (in tenths of a second) that the scale must be stable for motion status to be false (scale status = stable).

Example: 0 = disables motion detection.
 2 = 0.2 second delay before motion = false (stable = true).
 15 = 1.5 second delay.
 30 = 3.0 second delay.

Parameter 5: Motion Detection Band (6)

The motion band is used by the MOTION DETECT function to determine if the scale is in motion (not stable). If the amount of change between display updates is greater than the motion band, a MOTION status is generated (unstable condition). The motion band is entered in units of 1/4 dd, i.e.. For a motion band of:

1/2 display division enter	$1/2 \times 4 = 2.$
2 display divisions enter	$2 \times 4 = 8.$
4.5 display divisions enter	$4.5 \times 4 = 18.$

Parameter 6: Enable Display Blanking During Motion (No Blanking)

When display blanking is enabled, the display is blanked (turned off) when the scale is in motion (not stable). Enter a 1 (yes) to enable display blanking, enter a 0 (no) to disable display blanking.

Parameter 7: Zero Tracking Delay (1)

The automatic zero tracking function removes small deviations from zero. The IDS 410/422 adjusts the zero setting by approximately 1/30th of a display digit per delay interval. The delay interval is the number of A/D conversions between adjustments.

Parameter 8: Zero tracking band (12)

The zero tracking band is the maximum displacement from zero wherein zero tracking is active. In order for zero tracking to be active, the following conditions must be met:

- Scale weight is within Zero Track Band.
- Scale is stable (no motion)
- Zero Track Band is greater than 0 (zero).

The zero tracking band is entered in units of 1/4 dd, i.e.. for a band of:

1/2 display division enter	$1/2 \times 4 = 2.$
2 display divisions enter	$2 \times 4 = 8.$
4.5 display divisions enter	$4.5 \times 4 = 18$

Parameter 9: Push Button Zero Percent (100)

Enter the percent of full-scale capacity that can be acquired as the zero point with the ZERO key. 1 = 1%, 2 = 2%, 100 = 100%.

Parameter 10: Primary Units Type (1 [lb])

The scale is calibrated in the primary units. The UNITS key is used to toggle the weight display between primary units and alternate units. Enter the number that corresponds with the primary units:

- 0 = UNDEFINED, units are not printed.
- 1 = lb
- 2 = kg
- 3 = ton
- 4 = tne
- 5 = gram
- 6 = oz
- 7 = use print label 1 for units.
- 8 = use print code 1 for units.

NOTE: when parameter 10 is changed, parameters 13 and 16 must be programmed.

Parameter 11: Decimal Point Position (0 [no decimal point])

Enter the decimal point position for the primary unit's display. For example, if the scale is calibrated x 0.05 the decimal position = 2.

Parameter 12: Count-by (1)

Enter the primary unit's count-by. For example, if the scale is configured for:

- | | |
|--------|----------------|
| x 0.05 | count-by = 5 |
| x 0.2 | count-by = 2 |
| x 1 | count-by = 1 |
| x 5 | count-by = 5 |
| x 50 | count-by = 50 |
| x 100 | count-by = 100 |

Note: the entry for 0.05 and 5 is the same. The decimal point position (parameter 11) differentiates between the count-by 0.05 and count-by 5.

Parameter 13: Alternate Units Type (2 [kg])

Alternate units are the alternate display and print unit of measure that can be used in addition to the primary units. The UNITS switch on the IDS 410/422's keyboard toggles the weight display between primary units and secondary units.

0 = UNDEFINED, units are not printed.

1 = lb

2 = kg

3 = ton

4 = tne

5 = gram

6 = oz

7 = use print label 1 for units.

8 = use print code 1 for units.

Parameter 14: Alternate Decimal Point (1)

Enter the decimal point position for the alternate unit's display.

Parameter 15: Alternate Count-by (5)

Enter the alternate unit's count-by.

Parameter 16: Alternate Units Conversion Factor (45,360)

The IDS 410/422 calculates the alternate weight by multiplying the primary weight by the conversion factor and then dividing by 100,000.

The following table lists some common conversions.

Conversion	Conversion Factor	Conv. Fact. x 100,000
lb to kg	0.45359 kg/lb	45,359
kg to LB	2.20462 lb/kg	220,462
LB to Ton	0.0005 Ton/lb	50
kg to tonne	0.001 tonne/kg	100
gram to oz	0.352739 oz/gram	352,739
oz to gram	28.3495 gram/oz	2,834,950
lb to lb kb to kg etc.	1	100,000

Enter the conversion factor x 100,000 for the configured alternate units.

Parameter 17: Full Scale Graduations (10,000)

Enter the number of graduations at full scale. The full-scale graduations are calculated using the count-by, decimal position, and full-scale weight.

Full Scale Graduations = Full Scale Weight / count-by .

For example, if Full Scale Weight = 600.0 and count-by = 0.2 then Full Scale Graduations = $600.0 / 0.2 = 3000$.

Parameter 18: Overload Graduations (10,200)

Enter the number of graduations at which the scale is in overload status. The IDS 410/422 displays Err oL on the numeric display when the scale weight exceeds overload. For example, if the Full Scale Graduations is 10,000 grads and the scale is rated for 2% overload, then Overload Graduations = $10,000 + (10,000 \times 0.02) = 10,200$.

Parameter 19: Deadload Offset (1)

This parameter is automatically calculated by the calibration function.

Parameter 20: Disable Power-On Zero (1 [disabled])

Enter a 1 to disable the power-on zero function. Enter a 0 to enable power-on zero. The power-on zero function attempts to acquire zero when the power on tests have completed. If the weight on the scale is above the zero range the display prompts "Err 0". Press the ENTER key to view the scale weight. Remove the weight from the scale to enter weighing mode.

Parameter 21: Deadload Factor

The deadload factor is automatically calculated by the calibration function. This parameter is not accessible from the keyboard.

Parameter 22: Weight Conversion Factor

The weight conversion factor is automatically calculated by the calibration function. This parameter is not accessible from the keyboard.

Serial I/O Ports

The IDS 410/422 is equipped with two bi-directional serial communication ports that can communicate to an optional printer, a computer, bar code reader, a score board or other serial communication devices. The baud rate and format can be set independently for each port. Serial port 1 is normally used to output weight data and ID reports to a printer. Serial port 2 is normally used for continuous output of weight data. Continuous transmission can be enabled or disabled and the output format can be customized using the Continuous TX2 Format (Parameters 27 and 28).

Communication between serial devices requires that both devices have the same baud rate (transmission speed), data bit length, and parity. The mode parameter selects the data bit length and parity; the baud parameter selects the baud rate.

Parameter 23: Serial Port 1 Mode (4 [8 data bits, no parity])

Enter the mode number from the table below to select the mode parameter in the mode description column.

Mode Number	Mode Description
1	7 data bits, no parity
2	7 data bits, even parity
3	7 data bits, odd parity
4	8 data bits, no parity
5	8 data bits, even parity
6	8 data bits, odd parity

Parameter 24: Serial Port 1 Baud Rate (1 [9600 baud])

Enter the baud number from the table below to select baud rate in the baud description column.

Baud Number	Baud Description
1	9600 Baud
2	4800 Baud
3	2400 Baud
4	1200 Baud
5	600 Baud
6	300(19.2k Baud *HS)
7	150(38.4k Baud *HS)

*High Speed version only.

Parameter 25: Serial Port 2 Mode (4 [8 data bits, no parity])

Enter the mode number from the table below to select the mode parameter in the mode description column.

Mode Number	Mode Description
1	7 data bits, no parity
2	7 data bits, even parity
3	7 data bits, odd parity
4	8 data bits, no parity
5	8 data bits, even parity
6	8 data bits, odd parity

Parameter 26: Serial Port 2 Baud Rate (1 [9600 baud])

Enter the baud number from the table below to select baud rate in the baud description column.

Baud Number	Baud Description
1	9600 Baud
2	4800 Baud
3	2400 Baud
4	1200 Baud
5	600 Baud
6	300 (19.2k Baud *HS)
7	150 (38.4k Baud *HS)

*High Speed version only.

Parameter 27: TX2 Control / Station ID (255 [single station])

Serial Port 2 can be used for continuous transmission of scale data or as a network buss or for single station remote control.

- Enter a 0 to enable continuous transmission of data (parameter 28).
- Enter a station ID (1 to 254) for network buss configuration.
- Enter 255 for single station remote control.

Parameter 28: TX2 Format (2 Condec data format)

If parameter 27 is set to 0 (continuous tx), parameter 28 determines what is sent:

- 1-AND: <status>,<mode>,<polarity><weight><units><terminate>
 status: OL (overload), ST (stable), US (unstable, in motion)
 mode: GS (gross mode), NT (net mode)
 polarity: + (positive weight), - (negative weight)
 weight: 7 characters data, NOT zero blanked, with decimal point
 units: lb, kg, t (ton), tn (tonne), g<sp> (gram), oz
 terminate: lf, cr (line feed, carriage return)
- 2 - CONDEC: <stx><polarity><weight><units><mode>>status><terminate>
 polarity: space (positive weight), - (negative weight)
 weight: 7 characters, zero blanked, with decimal point
 units: L (lb), K (kg), T (ton), G (gram), O (oz)
 mode: G (gross mode), N (net mode)
 status: <space> (valid weight), M (motion), O (over wt), I (invalid)
 terminate: lf, cr (line feed, carriage return)
- 3 - WEIGHTRONIX: <mode1><mode2><polarity><weight><space><units><term>
 mode1: space (gross mode), 0 (zero if net mode)
 mode2: G (gross mode), N (net mode)
 polarity: + (positive weight), - (negative weight)
 weight: 6 characters, NOT zero blanked, with decimal point
 units: lb, kg, oz, g <space>(gram), t<space> (ton), tn (tonne)
 terminate: lf, cr (line feed, carriage return)
- 4 - OHAS: <polarity><weight><space><units><2 spaces><mode><status><term>
 polarity: space (positive weight), - (negative weight)
 weight: 7 digits, zero blanked, with decimal point
 units: lb, kg, oz, g <space>(gram), t<space> (ton), tn (tonne)
 mode: G (gross mode), N (net mode)
 status: <space> (valid weight), M (motion), O (over wt), I (invalid)
 terminate: lf, cr (line feed, carriage return)
- 5 - Label 85: Use parameter 85 (print label 85).

Print label 85: transmits the contents of parameter 85 (print label 85)

Data entered into a print label can include register data:

[253] [reg no] buffer register data, minimum size (zero blanked no spaces)

[254] [reg no] buffer data, 7 character field, zero blanked, right justified.

Printer Parameters

The IDS 410/422 provides a universal printer interface for various printers. The printer interface allows you to select and customize the data output for serial printers.

Parameter 30: Auto Print LF after CR (1 [yes])

Some printers require a line feed character (LF) to advance the paper and some printers advance the paper with only a carriage return character (CR).

Enter a 1 to automatically add a line feed after a carriage return.

Enter a 0 to NOT add a line feed after a carriage return.

Parameter 31: End of Print Character (12 [form feed])

The end of print character is sent to the printer at the end of a print transmission. If your printer requires a special character to release the paper or to form feed the paper, enter the code here. The ASCII chart in the appendix lists the ASCII codes and their numeric values. Enter a 0 (zero) if no end of print character is required.

Parameters 32, 33, 34, 84, 85, 86 and 87: Print Labels

The IDS 410/422 provide 7 programmable print labels. They are available for printing company name, address, station ID, or other messages. Labels 32, 33, and 34 have up to 16 characters. Labels 84, 85, 86, and 87 have up to 30 characters. Use the ASCII chart in the appendix to look up the numeric values of the ASCII codes. Remember to enter a 0 as the last entry of the print label.

Example: Select parameter 32 to begin Print Label 1 entry. The IDS 410/422 prompts "C0 xxx" where xxx is the current character 0 entry. For example, to enter IDS INC., enter:

C0	73	I
C1	68	D
C2	83	S
C3	32	(space)
C4	73	I
C5	78	N
C6	67	C
C7	46	(period)
C8	0	(end of print label)

Parameters 35, 36, 37, and 38: Print Codes

The IDS 410/422 provides 4 programmable print codes. The print codes are used to send special setup parameters to the printer, such as select print size or select print font. Each print code is up to 4 characters long. Consult your printer manual for the print codes that you may want to use. Enter the codes in decimal format (an ASCII carriage return = 13). Select parameter 35 to begin print code 1 entry. The IDS 410/422 prompts "C0 XXX" where xxx is the current character 0 print code value. Enter data for character 0. The IDS 410/422 prompts "C1 XXX". Continue the code entry. Enter a 0 to end print code entry.

Parameter 39: Enable TTL Remote Control (1 [enabled])

Use parameter 39 to enable remote control using TTL inputs 1 through 3 (TB3 terminals 8, 9 and 10).

Enter a 1 to activate scale basic functions 1 - 3. For example, grounding TB3 pin 8 (TTL input 1) activates scale basic function 1. Enter a 0 to disable TTL remote control.

Display Intensity, Watch Dog Timer

Parameter 40: Display Intensity (10)

Use parameter 40 to set the brightness of the IDS 410/422's numeric display and LED indicators. The brightness can be set from 1 (dimmiest) to 15 (brightest).

Parameter 41: Battery backup (0[off])

Parameter 41 is used to preserve the time and date, memory registers, and ID memory when power is lost. Set parameter 41 to ON (1) this will prevent the IDS 410/422 from clearing the memory when power is restored. Set parameter 41 to OFF (0) to erase memory when power is restored.

Parameter 42: Enable Watch Dog Timer (0 [no])

The watch dog timer resets the IDS 410/422 when the weight display is not updated within the time-out time (0.2 sec). Set the Enable ON (1) to reset after time-out. Set the Enable OFF (0) to turn off the watch dog timer.

Parameters 43-50: Fixed Registers

The Fixed Registers are used by the Trip-Level Event Monitor to determine when a trip-level is reached. These parameters are set by the Mode of Operation selection (parameter 73) as needed.

Parameters 51-56: Keyboard Event Functions

The keyboard event functions determine what actions take place when a key is pressed. The Power on start function activates a function when power is applied to the weight indicator. These parameters are set by the Mode of Operation selection (parameter 73) as needed.

Number	Parameter Name	Default Value	Password
51	Power on start function	0 (no function executed)	2
52	Print key function	136 (Print function)	2
53	Units key function	127 (Units toggle function)	2
54	Gross/Net key function	128 (Gross/Net toggle function)	2
55	Tare key function	129 (Tare function)	2
56	Zero key function	130 (Tare function)	2

PARAMETER FUNCTIONS

The parameter functions are used to set parameters that are too complex for a single numeric entry. The following table lists the parameter functions:

Parameter Functions

Fn. No.	Function Name	Password Level
59	Display Calibration Audit Number	0
60	Calibrate Scale - deadload first	3
61	Calibrate Scale - span first	3
62	Calibrate Deadload Only	3
63	Adjust Gain Calibration	3
64	Configure Passwords	2
65	Configure Print Formats	2
66	Set Time and Date	2
67	Display Operation Parameters	0
68	Print Operation Parameters	0
69	Diagnostic Tests	0
70	Initialize Operation Parameters to factory defaults.	3
71	Configure Event Monitor	2
72	Function Editor	2
73	Initialize Function Memory	2
74	Set Debug mode for Event monitors and Scale basic fns.	2
76	Set debug mode for event monitors and scale basic fns.	2
79	Enable multi-point linerization	2
80	Calibrate multi-point linerization	2

The Password Level is used to prevent unauthorized access to parameter functions. See Parameter Function 64, "Configure Passwords", for more information on password levels.

Parameter data entry uses the alternate keyboard functions (**clear**, **item**, **+**, **-**, **enter**). To enter/change numeric data, use the **item** key to select a digit to change. The digit blinking is the currently selected digit. Use the (+) and (-) keys to increase or decrease the selected digit. Press the **enter** key to accept the displayed number, press the **clear** key to discard the changes.

The parameters are accessed by holding the GROSS/NET key down and then pressing the UNITS key. The numeric display prompts "CFG xx", where xx is the currently selected parameter. Use the alternate key functions to select a parameter. Press the **enter** key to begin parameter data entry.

Press the **clear** key (when CFG xx is displayed) to exit configuration mode and store the parameter data into memory.

Function 59: Display Calibration Audit Number

Use function 59 to view the calibration audit number , the configuration number, the software ID number, and the status of the internal function lock.

The IDS 410/422 provides a calibration audit number and a configuration number. They are used to indicate changes to calibration data and configuration data and can be used in place of mechanical seals by some regulatory agencies. The IDS 410/422 audit number increments each time a calibration parameter is changed (deadload or weight conversion factor). The configuration number increments each time a password level 3 parameter is changed. If physical seals are used, then place the internal function lock in the locked position before sealing. Calibration and password level 3 parameters can not be accessed when the function lock is in the locked position.

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode.
- 2 Enter CFG 59. The IDS 410/422 prompts "A xxx" where xxx is the current audit number.
- 3 Press the ENTER key. The IDS 410/422 prompts "C xxxxx" where xxxxx is the current calibration number.
- 4 Press the ENTER key. The IDS 410/422 prompts "xxxxx" where xxxxx is the ID number of the software installed in the IDS 410/422.
- 5 Press the ENTER key. The IDS 410/422 prompts "un-LoC" if the function lock is in the unlocked position, or "Loc Ed" if the function is in the locked position.

Function 60: Calibrate Scale - Deadload First

Use function 60 to calibrate the scale by reading the deadload first and then reading the span. Set the Scale Operation Parameters before using function 60. Best results are obtained when the IDS 410/422 and load cells have reached thermal equilibrium (power applied for approximately 30 to 120 minutes depending on load cell size). NOTE: function 60 automatically adjusts parameter 19 (internal A/D deadload factor).

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode.
- 2 Enter CFG 60. The IDS 410/422 prompts "dEAdld". Remove all weight from the scale. Press the ENTER key. The IDS 410/422 reads the scale's deadload weight.
- 3 The IDS 410/422 prompts "CALib". Place the calibration weight on the scale. Enter the calibration weight using the **item**, +, - keys. Press the ENTER key. The IDS 410/422 reads the calibration weight.
- 4 The IDS 410/422 prompts "CFG 60". Press the CLEAR key to exit the configure mode.

Function 61: Calibrate Scale - Span First

Use function 61 to calibrate the scale by reading the span first and then reading the deadload. (This function does not change the internal A/D deadload factor). Set the Scale Operation Parameters before using function 61. Best results are obtained when the IDS 410/422 and load cells have reached thermal equilibrium (power applied for approximately 30 to 120 minutes depending on load cell size).

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode.
- 2 Enter CFG 61. The IDS 410/422 prompts "CALib". Place the calibration weight on the scale. Enter the calibration weight using the numeric keypad. Press the ENTER key. The IDS 410/422 reads the calibration weight.
- 3 The IDS 410/422 prompts "dEAdld". Remove all weight from the scale. Press the ENTER key. The IDS 410/422 reads the scale's deadload weight.
- 4 The IDS 410/422 prompts "CFG 61". Press the CLEAR key to exit the configure mode.

Function 62: Calibrate Deadload Only

Use function 62 to re-calibrate the deadload weight without affecting the span calibration. (Does not change internal A/D deadload factor).

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode.
- 2 Enter CFG 62. The IDS 410/422 prompts "dEAdld". Remove all weight from the scale. Press the ENTER key. The IDS 410/422 reads the scale's deadload weight.
- 3 The IDS 410/422 prompts "CFG 62". Press the CLEAR key to exit the configure mode.

Function 63: Adjust Gain Calibration

Use function 63 to make small adjustments to the span calibration. Zero the scale and then place a known weight on the scale. When this function is selected, the **item** key (alternate function key) can be pressed to change the gain adjustment factor between (1-10-100-1000-10000) the default adjustment factor is 1000.

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode.
- 2 Enter CFG 63. The IDS 410/422 displays the weight on the scale in (1- 10000) graduation increments depending on the gain adjustment factor selected through the **item** key. The least significant 2 display digits show the graduation increments.

3 Use the UNITS key (+) and the PRINT key (-) to increase or decrease the displayed weight until the displayed weight is the same as the weight on the scale. Press the CLEAR key to exit Adjust Gain procedure.

Function 64: Configure Passwords

Use function 64 to enter password data. The IDS 410/422 provides three security passwords that can be activated and entered to protect configuration data. Password 1 is used to protect I/O port configuration, setpoint, and event monitor data. Password 2 is used to protect calibration and scale configuration data. Security level 3 provides extra protection for password level 2 data. Security level 3 requires the entry of password 2 and the Function Lock inside the IDS 410/422 to be in the unlocked position. Password 3 will inhibit viewing, changing, and uploading of Scale Basic functions to a PC when password is active but will allow downloading a new Scale Basic program from the PC to the indicator. All passwords will be disabled once the new program has been downloaded into the indicator and should be reactivated.

The Operation Parameter Reference Table lists the configuration parameters and the password/security level required to access them. The IDS 410/422 prompts "PASS 1" when a parameter is selected that requires password level 1. If the entered password is incorrect, the IDS 410/422 displays "Error". Press the ENTER key to try again. Press the CLEAR to exit from password entry.

IMPORTANT NOTE: Write down the passwords and put them in a safe place. If you lose and forget a password, there is no way to access the protected functions.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 64. The IDS 410/422 prompts "P1 xxxx" where xxxx is the current password number. Enter a new password number or press the ENTER key to use the displayed number. Enter a 0 (zero) for the password number to disable the password.
3. The IDS 410/422 prompts "P2 xxxx". Enter password 2 data.
4. The IDS 410/422 prompts "P3 xxxx". Enter password 3 data.

Function 65: Configure Print Formats

Use function 65 to modify print formats to meet your print requirements. The print formats are grouped into PAGES that are used for generating print data onto a form. Each page is organized into rows and columns as follows:

Line No.	Column No.	Item No.

Line No. = Line number on the page to print the item on.

Column No. = Column position where item print begins.

Item No. = Item to print.

Print format design requires you to become familiar with the PAGE LIST and the PRINT ITEM LIST. The PAGE LIST describes how each PAGE is used. The PRINT ITEM LIST describes what ITEMS can be included in each page. Use the print format worksheets to design new print formats. The PRINT FORMAT DESIGN EXAMPLE illustrates how a print format is designed. A list of the default print formats is found in DEFAULT PRINT FORMATS. The print formats (PAGES) are initialized to factory settings when the Initialize System Parameters function is used. (Parameter Function 73).

Modify or Design a Print Format

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode. Enter CFG number 65.
- 2 The IDS 410/422 prompts "PAGE". Enter the Page number that you want to modify.
- 3 The IDS 410/422 prompts "Px E1" where x is the page number that you entered and E1 indicates that the current entry being modified is entry 1. Press the ENTER key.
- 4 The IDS 410/422 prompts "L x" where x is the line number on the page that entry 1 is to print on. Enter a new line number or press ENTER to use the displayed number.
- 5 The IDS 410/422 prompts "C x" where x is the column number on the page that entry 1 is to print on. Enter a new column number or press ENTER to use the displayed number.
- 6 The IDS 410/422 prompts "i x" where x is the item number that is to be printed. (see Print Item List for a description of items that can be printed). Enter a new item number or press the ENTER key to use the displayed number.
- 7 The IDS 410/422 prompts "Px E2". Use the procedure above to modify entry 2. Use the UNITS key (v) to scroll forward in the page table, use the PRINT key (^) to scroll backwards.
- 8 Enter a zero (0) for the line number (L 0) after the last entry that is to be printed. Press the CLEAR key to exit from the current page.

Page List

Format	Description
PAGE 1	Prints when in the GROSS weight mode.
PAGE 2	Prints when in the NET weight mode.
PAGE 3	Used by Scale Basic functions when needed.
PAGE 4	Used by Scale Basic function if needed.

Print Item List

Item #	Print Labels user configurable
2	Print Label 32 (see chapter 5: Set I/O Port Parameters, 32-34)
3	Print Label 33 (labels 32-87 are user configurable)
4	Print Label 34
84	Print label 84
85	Print label 85
86	Print label 86
87	Print label 87
88	Print label 88
89	Print label 89
90	Print label 90
Item #	Fixed labels non configurable
14	Primary units CFG 10 (lb, kg, ton, tne, grams, oz and labels)
36	(#) Number sign
139	"TOTAL"
140	"TOTAL GROSS"
141	"TOTAL TARE"
142	"TOTAL NET"
143	"SUBTOTAL GROSS"
144	"SUBTOTAL TARE"
145	"SUBTOTAL NET"
146	"NOT LEGAL FOR TRADE"
Item #	Time and Date
10	Time and Date
11	Time
12	Date
13	Stored Time
14	Stored Date

Item #	Weights with Units
5	Gross Weight (primary units)
6	Tare Weight (primary units)
7	Net Weight (primary units)
8	Gross Weight labeled "WEIGHT" (primary units)
9	Status of the indicator (inhibit character list)
15	Gross Weight (alternate units)
16	Tare Weight (alternate units)
17	Net Weight (alternate units)
18	The displayed weight (in the displayed units and mode)
19	Peak Gross Weight
20	Peak Net Weight
25	Gross Weight (display units)
26	Tare Weight (display units)
27	Net Weight (display units)
Item #	Print Codes and ASCII Codes
21	Print Code 1 (see chapter 5: Set I/O Port Parameters, 35-38)
22	Print Code 2
23	Print Code 3
24	Print Code 4
32	Space holder, does nothing.
33	Form Feed (ASCII 12)
34	Carriage Return (ASCII 13)
35	Line Feed (ASCII 10)

Item #	ID Registers
40	ID Number
41	ID Total weight
42	ID Register (2)
43	ID Register (3)
44	ID Register (4)
45	ID Register (5)
46	ID Register (6)
51-66	Memory Registers 1 through 9
67-74	Fixed Registers
100-109	Memory Registers 1 through 9 (with primary units label)
110	Memory Register 10 4 char wide with '#' sign

Print Format Design Example

EXAMPLE PRINT:

COLUMN	1234567890123456789012345678901234567890
LINE	
1	
2	
3	GROSS 54785 LB
4	TARE 12451 LB
5	NET 42243 LB
6	
7	TIME 03:45 PM DATE 06 AUG 91

EXAMPLE FORMAT DESIGN WORKSHEET:

Page:	Item Description	Line No.	Column	Item No.
1				
E1	Gross Weight	3	4	5
E2	Tare Weight	4	4	6
E3	Net Weight	5	4	7
E4	Time and Date	7	1	10
E5	End of Print	0	0	0

NOTE: A zero in the Line No column terminates printing. Use zero only after all required information has been entered. The maximum number of entries is 14.

Function 66: Set Time and Date

Use function 66 to set the time and date (optional clock chip must be installed in U5) NOTE: Battery backup parameter 41 should be set to (1) on so if the unit loses power the clock data will be saved.

Hold down the GROSS/NET key down and depress the UNITS key the 410/422 will prompt CFG xx key in 66 and enter, the 410/422 will prompt txxxx for the time data enter in the current time Use the + - keys to select 0 for am and 1 for pm or 2 for 24 hour clock as the last digit place txxxx1 on the display. Example: t11021. Depress the enter key when the time data has been set and the 410/422 will prompt the date, key in the current date. Example: 010100 for Jan, 01, 2000 and enter the time and date has now been stored.

Function 67: Display Operation Parameters

Use function 67 to view operation parameters. This function allows viewing the parameters when the password is not available.

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode.
- 2 Enter CFG 67. The IDS 410/422 prompts "PAR xx" where xx is the currently selected parameter number. Press the ENTER key to view the parameter data or enter a parameter number to view.
- 3 Press the CLEAR key to exit function 66.

Test No.	Hardware Tested	Description
1	Serial Com. Port 1	display input data.
2	Serial Com. Port 1	display input error count.
3	Serial Com. Port 1	transmit data.
4	Serial Com. Port 2	display input data.
5	Serial Com. Port 2	display input error count.
6	Serial Com. Port 2	transmit data.
7	TTL I/O test	Activates TTL 1-3 In and out.
8	A/D converter	display raw conversion data.
9	Ram Memory	test memory for errors.
10	Display	turn on all LED's and display segments.
11	EAROM data	Print the EAROM configuration data.
12	Serial Com. Port 1	Transmit/Receive loop-back test.
13	Serial Com. Port 2	Transmit/Receive loop-back test.

Function 68: Print Operation Parameters

Use function 68 to send the operation parameter data to the printer.

1. Hold the GROSS/NET key down and press the UNITS key to enter configure mode. Enter CFG 68. The IDS 410/422 prompts "Print". Press the ENTER key to print the operation parameters or press the CLEAR key to exit without printing.

Function 69: Diagnostic Tests

Use function 69 to access the IDS 410/422's built in diagnostic tests. See the chapter 7 - "Diagnostic Tests" for more information on the diagnostic tests.

- 1 Hold the GROSS/NET key down and press the UNITS key to enter configure mode.
- 2 Enter CFG 69. The IDS 410/422 prompts "diA xx" where xx is the currently selected test number. Enter a test number or press the ENTER key to use the displayed number.
- 3 The IDS 410/422 begins the selected test. Press the CLEAR key when the test is complete.

Function 70: Initialize Operation Parameters to Factory Defaults

Use function 70 to reset the IDS 410/422's operation parameters to their factory default values. This function also sets the calibration parameters to the factory default. Do NOT use this function unless you are ready to begin installation from the beginning.

- 1 Hold the GROSS / NET key down and press the UNITS key.
- 2 Enter CFG 70. The IDS 410/422 prompts "**rESEt**". Key in **10809** and press the ENTER key to reset operation parameters or press the **clear** key to exit without changing the operation parameters. If the 10809 code is to be used the unit will need to be recalibrated. **NOTE:** the code 10809 is not mandatory to initialize the 410/422.
- 3 After entering parameter 70 and the prompt "rESEt0" is being displayed depress the ENTER key, this will reset most of the registers to 0. For full initialization use the **10809 code**.

Function 71: Configure Event Monitor

Use function 71 to enter setpoint data into the Event Monitor. See the "Scale Basic / Event Monitor" manual for more information on the event monitor parameters.

Hold the CLEAR key down and press the ENTER key to enter the configure mode.

Enter CFG 71. The IDS 410/422 prompts "Eno". Enter the Event number to be modified.

The IDS440 prompts "P0 xx" where P0 is parameter 0 and xx is the current value of parameter 0. Enter new data for P0 or press the ENTER key to use the displayed data.

Use the UNITS key (↓) or the PRINT key (↑) to scroll through the parameter numbers. Press the CLEAR key to exit from the current Event number. Press the CLEAR key again to exit from event monitor data entry.

DIAGNOSTIC TESTS

The DIAGNOSTIC TESTS are accessed using configuration function 69. Hold the GROSS/NET key down and press the UNITS key to enter configure mode. The display prompts "CFG xx" where xx is the currently selected parameter. Enter **69** and press the ENTER key to access the DIAGNOSTIC TESTS.

The display prompts "diA xx" where xx is the last selected diagnostic function. Select a test number from the table below. Enter the test number and press the ENTER key.

Table of Diagnostic Tests

Test No.	Hardware Tested	Description
1	Serial Com. Port 1	Display input data.
2	Serial Com. Port 1	Display input error count.
3	Serial Com. Port 1	Transmit data.
4	Serial Com. Port 2	Display input data.
5	Serial Com. Port 2	Display input error count.
6	Serial Com. Port 2	Transmit data.
7	TTL I/O 1,2 &3.	Activate TTL out / in
8	A/D converter	Display raw conversion data.
9	Ram Memory	Test memory for errors.
10	Display	Turn on all LED's and display segments.
11	EAROM data	Print the EAROM configuration data.
12	Serial Com. Port 1	Transmit/Receive loop-back test.
13	Serial Com. Port 2	Transmit/Receive loop-back test.

Diagnostic Test 1: Serial Com Port 1 - Display Input Data

This test displays serial data as it is received by serial communications port 1. The numeric display has limited alpha display capability, however numeric and some alpha characters are legible. If all data being received is unintelligible, the baud rate is probably incorrect. If nothing is displayed on the display, then check the following:

1. RS232/Current switch on the main circuit board.
2. Cabling between the communicating units.
3. Make sure the sending unit is actually sending data.

Diagnostic Test 2: Serial Com Port 1 – Display Errors

This test displays the number of framing and parity errors that are detected in the input data stream. The error count is set to zero when entering this test. New errors are displayed as "PxxFxx" where Pxx is the number of parity errors and Fxx is the number of framing errors. If the error count exceeds 99, the display will remain at 99.

Diagnostic Test 3: Serial Com Port 1 - Transmit Data

This test transmits data out of serial communications port 1. The display prompts: "OUT 0". Press the **enter** key to send data. Serial Port 1 transmits "1234567890ABCDEF" and prompts "OUT 1" to indicate that 1 transmission has occurred. Press the **enter** key again or press the **clear** key to exit diagnostic test 3.

NOTE: If the error message "Er CtS" appears, the data can not be transmitted because the handshake signal, clear-to-send (TB1 pin 7), is low or not connected. If clear-to-send is not used, jumper it to data-terminal-ready (TB1 pin 4)

Diagnostic Test 4: Serial Com Port 2 - Display Input Data

This test displays serial data as it is received by serial communications port 2. The numeric display has limited alpha display capability, however numeric and some alpha characters are legible. If all data being received is unintelligible, the baud rate is probably incorrect. If nothing is displayed on the display, then check the following:

1. RS232/RS485 jumper on the main circuit board.
2. Cabling between the communicating units.
3. Make sure the sending unit is actually sending data. Press the **clear** key to exit diagnostic test 4.

Diagnostic Test 5: Serial Com Port 2 – Display Errors

This test displays the number of framing and parity errors that are detected in the input data stream. The error count is set to zero when entering this test. New errors are displayed as "PxxFxx" where Pxx is the number of parity errors and Fxx is the number of framing errors. If the error count exceeds 99, the display will remain at 99. Press the **clear** key to exit Diagnostic test 5.

Diagnostic Test 6: Serial Com Port 2 - Transmit Data

This test transmits data out of serial communications port 2. The display prompts: "OUT 0". Press the ENTER key to send data. Serial Port 2 transmits "1234567890ABCDEF" and prompts "OUT 1" to indicate that 1 transmission has occurred. Press the ENTER key again or press the **clear** key to exit diagnostic test 6.

Diagnostic Test 7: TTL I/O Test Inputs and Outputs

This test will test the TTL inputs and outputs. The 410/422 will display "out 111" depress the ENTER key and the display will display "out 011 and TTL 1 out will be activated. Depress the ENTER key again and the display will display "out 101" and TTL 2 out will be activated. Depress the ENTER key again and the display will display "out 110 and the TTL 3 out will be activated. Depress the ENTER key again and the display will display "in 11" ground terminal 8, 9 or 10 to ground and the 410/422 will exit the TTL test, displaying "diAG 7".

Diagnostic Test 8: Test A/D

This test displays the (filtered) raw data being read from the A/D converter. Use this test to determine optimum deadload and gain settings. If the number displayed at deadload is less than 1000 or greater than 250,000 then use the deadload offset (parameter 19) to add or subtract deadload from the signal input. NOTE: deadload offset (parameter 19) is automatically set using the calibration function 60. If the full scale number displayed is less than 380,000 then use the "loadcell mv/V" parameter to increase the gain. If the full scale signal is greater than 1,000,000 then use the "loadcell mv/V" parameter to decrease the gain.

If no data is being displayed, the A/D converter is "locked up". Turn power off and then on and re-activate the test. Check load cell wiring for reversed signal or excitation signals.

Press the PRINT key to scroll the AD test function from:

1. display raw data (digital filter on).
2. display and transmit via serial port 2, raw data (digital filter off).
3. display A/D noise factor. Press the ENTER key to clear noise factor to 0.

Press the MENU key to exit AD test.

Diagnostic Test 9: Perform Internal Memory Test

This test writes data to memory and then reads it back to test for failed memory locations. The existing data in memory is not affected by this test. The display prompts "r TEST" while the test is in progress. The display prompts "PAS 32" if the test is successful. If an error is detected the "Exxxx" is displayed, where xxxx is the location of the error.

Diagnostic Test 10: Lamp Test

This test turns on all the LED displays and numeric display segments. Replace any LED or display that does not illuminate.

Press the Clear key to exit diagnostic test 10.

Diagnostic Test 11: Print the EAROM Configuration Table

This function sends the contents of the EAROM configuration memory to the printer. Use this function to document your setup of the when installation is complete.

Diagnostic Test 12: Serial Communications Port 1 - Loop Back Test

This test is used by the factory to test the serial ports transmit and receive functions. The transmit and receive lines must be jumpered together and the clear-to-send must be jumpered to data-terminal-ready for this test.

Diagnostic Test 13: Serial Communications Port 2 - Loop Back Test

This test is used by the factory to test the serial ports transmit and receive functions. The transmit and receive lines must be jumpered together for this test.

Diagnostic Test 14: Display Time and Date

This test will display the Time and Date. **Note:** The optional clock must be installed.

Function 72: Scale Basic Function Editor

Use function 72 to create or modify Scale Basic Functions. See the “ Scale Basic / Event Monitor” manual for more information on Scale Basic Functions.

1. Hold down the GROSS/NET key and depress the UNITS key to enter the configuration mode.
2. Enter CFG 72. The IDS 410/422 prompts “Fn”. Enter the function number to be modified.
3. The IDS 410/422 prompts “0-xxx” where 0- is the entry zero, and xxx is the current value for entry zero. Enter new data for 0- or press the ENTER key to use the displayed data.
4. Use the UNITS key – or the GROSS/NET key + to scroll through the entry numbers. Press the CLEAR key to exit from the function editor.

Parameter 73: Mode of Operation

Parameter 73 selects one of the following Modes of Operation:

- 0 - Normal
- 1 - Keyboard Tare
- 2 - Print weight and Total
- 3 - Print weight with Subtotal & Total
- 4 - Multi-Container/Axle Weighing
- 5 - Auto Weight and Print (Auto Axle Weigh)
- 6 - Auto-Axle Weigh (Long Scales)
- 7 - Peak Hold
- 8 - Over / Under Checkweigh
- 9 - Bulkweigh

Chapter 4 of this manual describes the modes of operation. Enter the mode number that you want to use in your application.

Function 74: Configure Timers

The display prompts “tr” when function 74 is activated. Enter the timer number to be modified (1-5) then press the ENTER key. The first parameter (L) is the time length in tenths of a second. The second parameter (Fn) is the function number to be executed when the timer times out. Timer #5 reloads after it counts down to zero. This provides more accurate timing of repetitive events (such as pulse output, speed calculations and interval timing, etc.) See timer events in the Scale Basic programming guide.

Parameter 76: Debug Mode for Event Monitors and Scale Basic

The debug mode is used to debug event monitors and scale basic functions. Enter a 1 to activate debug mode, enter a 0 to diable debug mode. When debug mode is enabled Scale Basic functions single step. The subroutine stack level and the function number are displayed when entering a function. EXAMPLE: “0 F12”. Press the ENTER key to begin execution of the function. The instruction address and instruction code is displayed. EXAMPLE: “21 255”. Continue to press the ENTER key to step through the program. NOTE: the first step displayed for all Scale Basic funtions is a GOTO (244).

Function 78: Initialize ID Memory

Use function 78 to initialize ID memory after it has been corrupted. The ID memory can become corrupted when power is lost (when no battery is installed) or when the battery is allowed to discharge below 2 volts.

Parameter 79: Enable Multi-Point Linearization

Enter a 1 to enable multi-point linearization, enter a 0 to disable. The IDS 410/422 uses the calibration factors set in parameter 80 below when multi-point linearization is enabled.

Function 80: Calibrate Multi-Point Linearization

•NOTE: Parameter 79 must be set to (1) first before using Multi-point calibration.

Use function 80 to calibrate the scale using up to five calibration points to linearize the load cells. Set the Scale Operation Parameters before using function 80. Best results are obtained when the IDS 410/422 and the load cells have been allowed to reach thermal equilibrium (power supplied for approximately 30 to 120 minutes depending upon load cell size). NOTE: funtion 80 automatically adjusts parameter 19 (deadload offset).

1. Hold the GROSS/NET key down and depress the UNITS key to enter the CFG mode.
2. Enter CFG 80. The IDS 410/422's display will prompt "dEAdld". Remove all weight from the scale. Press the ENTER key to obtain the deadload weight. Press the UNITS key to continue without reading a new deadload weight.
3. The IDS 410/422's display will alternates between "CAL1" and the weight on the scale. Place the first calibration weight on the scale. Enter the calibration weight using the key pad. Press the ENTER key. The IDS 410/422 reads the calibration weight.
4. The IDS 410/422's display alternates between "CAL2" and the weight on the scale. Repete step3. The IDS 410/422 will accept up to five calibration points. Press the CLEAR key to complete calibration if less than five points are used.
5. The IDS 410/422 will prompt "CFG80". Press the CLEAR key to exit the configuration mode.

Troubleshooting

Problems and probable cause

The following table describes the probable causes to some problems you may encounter. Most problems can be resolved by using the information provided in the table.

Problem	Probable Causes
Printer does not print (serial RS232)	<ul style="list-style-type: none"> * Cable connection problem or invalid pin connections. * Baud rate and format on serial port 1 does not match printer. * Printer is not ready or it is busy. * Transmitter/receiver IC damaged (U3 RS232).
Continuous output does not update	<ul style="list-style-type: none"> * “TX CONTINUOUS” disabled (configuration Parameter 27 to 0) * Cable connection problem or invalid pin connections. * Baud rate and format on serial port 2 does not match receiver. * Transmitter/receiver IC damaged (U3 RS232).
Input port 1 not working	<ul style="list-style-type: none"> * Baud rate and format on serial port 1 does not match host. *Cable connection problem or invalid pin connections. *RS232 transmitter/receiver IC damaged (U3 RS232).
Input port 2 not working	<ul style="list-style-type: none"> * Baud rate and format on serial port 2 does not match host. * Cable connection problem or invalid pin connections. * Internal jumper JP3 (RS232/422/485/CL) not set properly. * RS232 transmitter/receiver IC damaged (U3 RS232). * RS422/485 transmitter/receiver IC damaged (RS422{U11 75176} RS485{U7 75176}).
“Er CtS” error message.	<ul style="list-style-type: none"> * Cable connection problem. * Printer is not ready or it is busy. * Transmitter/receiver IC damaged (U3 RS232).
Invalid weight display or weight fluctuating	<ul style="list-style-type: none"> * Invalid calibration parameters.* Load cell or load cell input cable problems.

Error Messages

Error No.	Description
Err 1	Keyboard error. Occurs during power up while a key on the keyboard is being pressed or one of the remote switch inputs is activated.
Err 2	Restart Trap. The microprocessor accessed nonexistent memory location. Usual cause is A/C power "glitch" or static electric discharge.
Err 3	Watchdog Timeout. The weight display has not been updated within the watchdog time-out period. Usual cause is A/C power glitch or static electric discharge.
Err 4	Battery Error. (Optional) battery voltage level was below 2 V when the 410/422 was powered off.
Err 5	Earom memory error. A checksum error has occurred when reading the configuration earom memory. Check calibration parameters and rewrite the earom memory. If error continues, replace earom (U12).
Err 5	Earom Timeout, unable to write to the earom memory.
Err 6	Ram memory error. A ram memory error has occurred. Replace U5 if error continues.
Err 7	The A/D converter is "locked up". Check load cell wiring.
Err 8	Negative deadload error.
Err 9	Count-by error. The entered value is outside the scale count-by set during calibration.
Err 10	Push button zero error.
Err 11	A to D convertor not working. Check load cell wiring.
Err 12	Negative deadload. Check loadcell wiring. Enter a deadload offset in configuration parameter 19.
Err 14	Page Format line length error. The page format output exceeded the maximum line length.
Err 15	The function selected is locked. Switch S1 on the IDS 410/422's circuit board locks and unlocks configuration parameters.
Err 16	Scale Basic Stack Overflow. Too many setpoints in user function running simutainuously.
Err 18	Referenced a Function Instruction that does not exists.
Err 21	ID not found.
Err 22	Scale Basic Prompt error.
Err 23	ID memory full.
Err 24	Link list error.
Error OL	Calibration error or scale is over-loaded (above scale capacity).
undEr	Calibration error or scale is under-loaded (below readable weight).
SuSPEn	Scale Basic executed a RESUME instruction without a corisponding SUSPEND instruction.

HARDWARE INSTALLATION AND WIRING

This section describes installation and wiring information for the interface ports. There are two bi-directional serial ports, digital port with 3 TTL inputs, 3 TTL outputs, and one load cell input port. The serial ports are used to interface to a printer and to a host device or PC for continuous output. The TTL outputs and inputs are used for remote switch input and relay control. The load cell input is used to interface to the scale platform.

Load Cell Connector – TB1

NOTE: Remove jumpers JP1 and JP2 to enable SENSE LINES for 6 wire load cells. Wire the sheilding from the load cells to the chassis not TB1 pin 7.

Load Cell Terminal Block – TB1

Pin #	Signal Name
1	+ Signal
2	- Signal
3	+ Excitation
4	+ Sense
5	- Sense
6	- Excitation
7	Analog ground (NOT FOR SHIELD)

Power Source AC / DC

The unit come standard with an onboard transformer the AC interface connector is a 3 pin Molex type, this connects to the motherboard where the 3 pin Molex header is mounted on the board marked A/C power.

For DC power applications there ia a 2 position terminal block marked PWR-DC. Note the polarity of the terminals the positive is marked as (+) the negative (-). The DC power input will exept +12 to +28 VDC. Remove AC power before wiring for DC.

I/O Port Connector - TB 3

The I/O port connector has Com Ports 1 and 2 and the digital TTL inputs.


Pin #	Signal Name
1	+5V (TX- 20 mA CL)
2	TXD 1 (RS232)
3	RXD1 (RS232)
4	Soft +5 volts (220 ohm to +5V)
5	GND
6	CL TX +

7	GND
8	TTL IN 1
9	TTL IN 2
10	TTL IN 3
11	TXD 2 (RS232) (TX+ 20mA CL)
12	RXD 2 (RS232)
13	RS485 TX -
14	RS485 TX +
15	RS485 RX -
16	RS485 RX +

Digital Output Port Connector TB4

1	TTL OUT 1
2	TTL OUT 2
3	TTL OUT 3
4	GROUND


P.C. Board Diagram - Connectors, Jumpers, and Switches



ISOLATED ANALOG OUTPUT OPTION

IDS410/422-AO

The Analog Output option board is internally mounted inside the IDS indicator. The Analog Output has two jumpers; JP1 & JP2. These jumpers are used to configure the output format. Terminal block TB1 is for making external wiring connections. JP1 & JP2 are factory set for 4-20mA. Refer to the diagram below for configuration, format and alternative wiring. No interconnect cables are provided by the factory, the recommended cables used should be suitable for the conduit fittings and should comply with National Electrical code requirements.



INSTALLATION OF ANALOG OUTPUT BOARD

Before installation, remove power from the IDS indicator and remove the back plate to access the internal board. Refer to the drawings below to locate the installation connector and stand off holes on the IDS 410/422 weight indicators. Install the (2) plastic standoffs into the holes on the CPU board and plug the analog output board (J1) onto the analog output connector. Secure the analog output module to the CPU board by pushing the standoffs through the holes on the module. Set JP1 and JP2 according to the desired output and connect the external device to TB1 according to the selected output. Apply power to the IDS indicator and configure parameters 81, 82, and 83 as described in the table below.

SETUP PARAMETERS

For proper operation, the following parameters are used to configure the operation of the analog output.

Parameter	Description	Default Value
81	Analog output span (20ma). The value entered here is the display graduations (weight/count-by) and must correspond with the full scale digits set in parameter 17	10,000
82	Analog output offset (4ma). The value entered here is the display graduations (weight/count-by) and must correspond with the full scale digits set in parameter 17	0

83	Analog output register/mode: 64 = Gross, 65 = Tare, 66 = Net (Note: Scale Basic provides other registers (1-61,43-50, 64-68) which can be set based on a mathematical formula)	0
----	--	---

SCALE SPECIFICATIONS

Display	Bright red LED; 1-inch x 6-digit numeric
Status Indicators	Gross, Net, Motion, Zero, LB, kg (LED)
Keyboard	5-key sealed tactile feel membrane
Internal Resolution	20-bit A/D Sigma-Delta; 1,048,000 d
Display Resolution	200,000 dd industrial; 10,000 dd HB44
Display Increments	Selectable 1, 2, 5, 10, 20, 50 100
Decimal Point	Selectable 0, 1, 2, 3, 4 decimal places
Conversation Rate	60 samples/second typical
Signal Sensitivity	0.1 uV/graduation (min)
Signal Range	0.5 mV/V to 6mV/V
Load Cell Excitation	10 ± 0.5VDC (-5 to +5)
Load Cell Power	12 x 350 Ω or 24 x 700 Ω load cells
Auto Zero Tracking	0-60 dd in 1/4 dd increments
Auto Zero Delay	0-25 seconds In 0.1 second increments
Motion Detect	0-60 dd in 1/4 dd increments
Motion Delay	0-25 seconds In 0.1 second increments
Digital Filter	0-18 selectable filter (DSP) levels
Calibration	Selectable multi-point (up to 5) digital calibration to linearize input signal
Watchdog Timer	Enable/disable fault tolerant operation
RFI Protection	Signal, excitation and sense lines
RAM	32K provides 500 ID storage (parts, etc)

COMMUNICATIONS

Serial Port 1	Simplex RS232 or 20mA current loop
Serial Port 2	Full duplex RS232, 20ma or RS485
Digital Port	3 inputs and 3 outputs; Low active (TTL)
Print Formats	4 user configurable print formats

GENERAL SPECIFICATIONS

Power	110/220VAC ±10% @ 50/60Hz or 12-28 VDC
Power Consumption	10W @ 115VAC; 6W @ 12VDC
Operating Temperature	-10 to +40 °C.
Weight	6 lbs (2.72 kg)
Warranty	One-year limited

OPTIONS

Analog Output Module	Fully isolated 0-10VDC or 4-20mA; 16-bit resolution; 650Ω load resistance
Relay Box	4-channel external relay box
Relay Modules	Input/output solid-state (AC/DC) relays
Clock Module	Time and Date Clock Y2K and Leap Year
High speed (HS)	100 samples/second conversion rate; high-speed process control applications
EZ-LINK™	PC software; facilitates configuration and Scale Basic programming
IS Barriers	Hazard location intrinsic safety barriers
Panel Mount Kit	Mounts enclosure to user panel (for future release)
DeviceNet	PLC/COM interface (for future release)
Profibus	PLC/COM interface (for future release)

APPROVALS

NTEP COC# 96-133-A1 Canada Am-5216Rev1
 UL & CUL pending

The IDS 410 is the only digital weight meter in its class that is fully programmable in an easy and flexible macro language called Scale Basic™. In addition to the built-in modes of operation, Scale Basic allows you to customize the operation of the IDS 410 to meet your application requirements. The Scale Basic language provides various commands and functions that include: math operations, I/O control, setpoints, timers, data entry, ID storage, message display, and program sequence control among others. Programming the IDS 410 can be performed through the keyboard or a PC using the optional EZ-LINK™ software that greatly facilitates setup and programming.

MODE 0 - Normal

Basic gross, tare and net weighing

MODE 1 - Keyboard Tare

Same as Mode 0 but tare weight is keyboard entered

MODE 2 - Print Weight and Total

Print multiple gross or net weights and keep a running total for job, lot, etc. Print accumulated gross, tare and net totals at the end

MODE 3 - Print Weight With Subtotal and Total

Same as Mode 2 but subtotals can be printed.

MODE 4 - Multi-Container/Axle Weighing

Push the PRINT button to sequentially number and print a series of weighments. Push the TOTAL button to print and clear the total

MODE 5 - Auto Weigh and Print (Auto Axle Weigh)

Same as Mode 4 but printing is automatic when weights are placed on the scale. Provides traffic light control and trip level configuration

MODE 6 - Auto Axle Weigh (Long Scales)

Same as Mode 5 but previous axles are auto tared

MODE 7 - Peak Hold Mode

Display or print the gross or net peak weight detected

MODE 8 - Over/Under Checkweigh


Provides 3 TTL outputs and 2 setpoints to indicate over, under and between weight conditions. Outputs can activate lights or alarms

MODE 9 - Bulkweigh

Provides setpoint entry and relay output to control fill process. Remote start/stop operation with configurable scale empty and draft weights. Use for multiple drafts with subtotal and total printing

DIMENSIONS

- A = 7.63" (19.38 cm)
- B = 6.88" (17.48 cm)
- C = 8.56" (21.74 cm)
- D = 2.00" (5.08 cm) E = 3.00" (7.62 cm)



ASCII CHART

ASCII	DEC	ASCII	DEC	ASCII	DEC	ASCII	DEC
Null	00	SP	32	@	64	`	96
SOH	01	!	33	A	65	a	97
STX	02	"	34	B	66	b	98
ETX	03	#	35	C	67	c	99
EOT	04	\$	36	D	68	d	100
ENQ	05	%	37	E	69	e	101
ACK	06	&	38	F	70	f	102
Bell	07	'	39	G	71	g	103
BS	08	(40	H	72	h	104
HT	09)	41	I	73	i	105
LF	10	*	42	J	74	j	106
VT	11	+	43	K	75	k	107
FF	12	,	44	L	76	l	108
CR	13	-	45	M	77	m	109
SO	14	.	46	N	78	n	110
SI	15	/	47	O	79	o	111
DLE	16	0	48	P	80	p	112
XON	17	1	49	Q	81	q	113
TAPE	18	2	50	R	82	r	114
XOFF	19	3	51	S	83	s	115
DC4	20	4	52	T	84	t	116
NAK	21	5	53	U	85	u	117
SYN	22	6	54	V	86	v	118
ETB	23	7	55	W	87	w	119
CAN	24	8	56	X	88	x	120
EM	25	9	57	Y	89	y	121
SUB	26	:	58	Z	90	z	122
ESC	27	;	59	[91	{	123
FS	28	>	60	\	92		124
GS	29	=	61]	93	}	125
RS	30	>	62	^	94	~	126
US	31	?	63	<-	95	DEL	127