

# Load Cell Central

1-800-LOADCEL

## WEIGHING INDICATOR SERIES IPE50

### *User manual 1/2 For calibration and basic function*

*See user manual 2/2 for special functioning mode and output RS232/485, this manual is available on our  
Website [www.800loadcel.com](http://www.800loadcel.com)  
(valid from version 07.03)*



Load Cell Central follows a policy of continuous improvement and reserves the right to change specifications without notice. © 2014

**Load Cell Central**  
28175 Route 220  
Milan, PA 18831

Web: [www.800loadcel.com](http://www.800loadcel.com)  
Email: [sales@800loadcel.com](mailto:sales@800loadcel.com)

**Toll Free: 1-800-562-3235**  
Ph: 1-570-731-7048  
Fax: 1-570-731-7054

# INDEX

1	INTRODUCTION	P3
2	MAIN TECHNICAL SPECIFICATIONS	P4
3	DIMENSIONS	P5
4	POWER SUPPLY & START-UP	P8
5	FRONT PANEL KEYS AND INDICATORS	P8
6	BASIC FUNCTIONS	P10
7	SELECTABLE OPERATING MODES	P10
	7.5 Setpoint adjustment	P13
8	INSTRUMENT MESSAGES WHILE IN USE	P15
9	BLOCK DIAGRAM	P16
10	SETUP	P19
11	ADJUSTMENT	P25
12	ANALOG OUTPUT	P30
13	ERROR MESSAGES	P31

# 1 INTRODUCTION

The purpose of this manual is to help the user get to know the weight indicator's various functioning modes, the keys' functions and the display indications

We advise to carefully follow the instructions for programming the weight indicator; by taking actions not indicated this manual, one could cause the scale to not work properly.

In addition to having all the characteristics of a high precision scale, the indicator has the kg/lb conversion function, the gross weight / net weight conversion, set point on gross weight or net weight, in/out weigh, repeater in r.f. transmission, alibi memory, hold function, peak detector, weighs totaliser and piece counter.

The indicator adapts to normal weighing applications in either industrial settings, such as during factory production processes, or that of commerce, such as legal for trade applications, also satisfying the frequently needed ability to transmit and print the data through its two bidirectional serial ports.

This manual has been made as carefully and exactly as possible; in any case, your suggestions are always welcome.



Any attempt to repair or alter the unit can expose the user to the danger of electric shock and it will void our warranty. This instrument is covered under warranty provided that **IT HAS NOT BEEN OPENED BY THE USER** for any reason. If any problem with the unit or system has been experienced please notify the manufacturer or the dealer from which the instrument was acquired.

**Do not pour liquids on the indicator!**

**Do not use solvents to clean the indicator!**

**Do not expose instrument to either direct sun light or any heat sources!**

**Always mount the indicator and platform in a vibration free setting!**

**Read carefully & apply what described in the POWER SUPPLY & START-UP section!**

**Do not install in an environment with any risk of explosion!**

## 2. MAIN TECHNICAL SPECIFICATIONS

POWER SUPPLY 12 to 24Vdc / 3.6 W max (110/220Vac for IPE50XLI)

OPERATING TEMPERATURE From -10 to +40 °C (14 to 104 °F).

DISPLAYED DIVISIONS 10000e, 2X3000e for legal for trade use expandable to 800.000 for internal use (with **minimum** signal coming from the 1.6mV/V cell).

RESOLUTION IN CALCULATION 150'000 points (with signal in input equal to 3mV/V).

MAX INPUT 30mV (6mV/V)

DISPLAY 6 digits, 13 millimetres high

STATUS INDICATIONS 6 LEDES

KEYBOARD water resistant polycarbonate membrane keys with tactile and acoustic feedback.

TARE FUNCTION Available on entire range, from keyboard or from optional remote control. Subtraction function on all models.

LOAD CELL POWER SUPPLY 5Vdc  $\pm$  5%, 120mA (max 8 cells of 350 Ohm)

LOAD CELL CONNECTIONS 4 or 6 wires with Remote Sense



PROTECTIVE CASE IP54, PVC case

SERIAL OUTPUTS (1) RS232 and (1) RS485 uni directional or bi directional configurable for connection to PC/PLC, printer, repeater.

**THE PARTS OF THE INSTRUMENT CONTAINING DANGEROUS ELECTRICAL TENSION ARE ISOLATED AND INACCESSIBLE TO THE USER UNLESS IT HAS BEEN DAMAGED, OPENED, OR ALTERED.**


### 3. DIMENSIONS :

#### IPE50 PANEL




- 1 and 2 Connection of power supply (12 to 24Vdc)
- 3 connection of the 2 inputs, the contact of setpoints and RS232 and 485
- 4 connection of sensors
- 5 connection of the 2 to 6 contact relays (6 relays in option)

# IPE 50 DIN



- 1 and 2 Connection of power supply (12 to 24Vdc)
- 3 connection of the 2 inputs, the contact of setpoints and RS232 and 485
- 4 connection of 1 to 4 sensors

IPE50 XLI



- 1: gland for power supply connection 110/220Vac
- 2: gland for sensor connection

## 4. POWER SUPPLY & START UP

Do not connect other equipment to the same socket as the one that the adapter is in.  
Do not step on or crush the power supply cable

Power supply for IPE50 is from 12 to 25VDC (except IPE50XLI)

The display shows in sequence:

**07.xx** indicate the version of software if you press the key ->0<-  
**09.01** 09 indicate the type of unit, 01 indicate the metrological software version  
**XX.YY.ZZ** version of the installed software.  
**DGTX** name of software  
**Ex :15001** the max capacity and the round  
**CloCK** if the option timer is installed.

After this, the programmed capacity and minimum division are displayed; then the instrument executes a countdown (self-check) and finally "hi rES" is displayed (in case of non approved instrument) or "LEGAL" and the calibration area (in case of approved instrument).

The indicator has an "auto zero at start-up" function: in other words it means that, with a non approved instrument the display shows the present weight after a few instants, while with an approved instrument "ZerO" is shown continuously on the display, until the weight does not re-enter within this tolerance; the auto zero function at start-up may be disabled in the set-up environment (only with non approved instrument); see **SEtuP >> ConFiG >> Param. >> Auto-0 (TECH.MAN.REF.)**


**TO stand by** the IPE50, keep the C key pressed until the - OFF – message appears on the display; then release the key (the power supply of the sensors 5V is always present).

Press the C key to restart the unit.

**To TURN OFF** the IPE50, switch off the power supply

## 5 IPE50 FRONT PANEL KEYS AND INDICATORS

The front panel of the indicator is designed for quick but simple weighing applications. It consists of an LED display with 6 digits 13 mm in height, 6 LED indicators and a keyboard 5 function keys.



LED	FONCTIONS
->0<-	Indicates that the weight detected on the weighing system is near zero, within the interval of -1/4 to +1/4 of the division.
~	Indicates that the weight is unstable.
NET	Indicates that the displayed weight is a net weight.
SPE	Indique que l'IPE50P est dans un mode de fonctionnement particulier
W1/ SP1 ou W2 / SP2	W1 or W2 show the functioning with 2 weighing ranges SP1 or SP2 Indicates that the relay 1 or 2 has been enabled.

SCALE KEY	FUNCTION
	<ul style="list-style-type: none"> <li>- Zeros the displayed gross weight, if is within +/- 2 to 50% of the total capacity.(2% max in trade mode)</li> <li>- Cancels the negative tare value.</li> </ul>
	<ul style="list-style-type: none"> <li>- If pressed for an instant it carries out the semiautomatic tare.</li> <li>- If pressed at length it allows entering the manual tare from keyboard.</li> <li>- Cancels the negative tare value.</li> <li>- In the numeric input phase it increases the digit to be modified.</li> </ul>
	<ul style="list-style-type: none"> <li>- It carries out a specific function of the operating mode set in the set-up environment.</li> <li>- In the numeric input phase it selects the digit to be modified, from left to right.</li> </ul>
	<ul style="list-style-type: none"> <li>- It carries out a specific function of the operating mode set in the set-up environment.</li> <li>- In the numeric input phase, it confirms the entry made.</li> <li>- In the SET-UP, it allows to enter a step or to confirm a parameter within a step.</li> <li>- It transmits the data from the serial port dedicated to the printer.</li> </ul>
	<ul style="list-style-type: none"> <li>- It turns the instrument in the mode stand by.</li> <li>- In the numeric input phase, it quickly zeros the present value.</li> <li>- In the set-up environment, it allows to exit a step without confirming the change made.</li> <li>- Cancel a tare</li> </ul>

## 6 BASIC FUNCTIONS

It will be necessary to go to different menus to modify some parameters.

To enter into these menus, turn on the unit, press the ->0<- key when 07.xx is displayed, after 09.01, DGT and the version of the software are displayed, press ->T<- key during the countdown the display shows the first parameter "TyPE".

### 6.1 ZERO SCALE

By pressing the ->0<- key, it is possible to zero a gross weight value which is within +/- 2% of the capacity; after the zeroing, the display shows 0 weight and the LED ->0<- is turned on.

### 6.2 TARE OPERATIONS

#### SEMI-AUTOMATIC TARE

By pressing the ->T<- key any weight value present on the display is tarred: the display shows "tArE" for an instant and then 0 (net weight); the relative keys turn on.

In any case a new tare operation cancels and substitutes the previous one.

**NOTE:** The semiautomatic tare will be acquire only if the weight is AT LEAST A DIVISION, STABLE (instability ~ led off) and VALID (in other words, the OVERLOAD condition should not be created).

#### ENTERING THE MANUAL TARE FROM KEYBOARD

Press ->T<- for a few seconds: the display shows "- tM -" and then "000000". Enter the desired value using the following keys:

->0<- decreases the blinking digit.

->T<- increases the blinking digit.

**MODE** selects the digit to be modified (blinking); the scrolling of the digits takes place from left to right.

**C** if pressed for an instant it quickly zeros the present value; if pressed at length it allows to return to weighing without saving the changes made.

**NOTE:** With the IPE50P one enters the value directly with the numeric keyboard

Confirm with the  $\square$  key; the value will be subtracted from the weight present on the plate and the relative pilot lights will turn on.

**If the entered value is not a multiple of the scale's minimum division, it will be rounded up if it is equal or greater than half of the division, or rounded down if lower.**

In any case a new tare operation cancels and substitutes the preceding one.

#### CANCELLING A TARE

One can manually cancel the tare value in different ways:

- unload the scale and press the ->0<- or ->T<- key.

- carry out the tares in deduction, partially unloading the scale and pressing ->T<- to zero the display.

- press C without unloading the scale.

- enter a manual tare equal to 0.

**NOTE:** it is possible to automatically cancel the tare value; see the section "LOCKED/UNLOCKED/DISABLED TARE SELECTION".

#### SELECTION OF LOCKED / UNLOCKED / DISABLED TARE

Normally, when a tare value is entered (automatic, manual, or from storage) by unloading the scale plate, the display shows the tare value with a negative sign (LOCKED TARE). For one's convenience it is also possible to choose that the tare value cancels itself automatically each time that the scale is unloaded (UNLOCKED TARE); or disable the tare functions.

With the UNLOCKED tare:

**In case of SEMIAUTOMATIC TARE the net weight, before unloading the scale, may also be 0.**

In case of MANUAL TARE or FROM DATABASE the net weight before unloading the scale must be of at least 2 stable divisions.


To set the type of tare:

- Select menu F.Mode.
  - Press  $\downarrow$  to enter the menu.
  - Press  $\rightarrow 0 \leftarrow$  many times (to scroll ahead through the parameters) or  $\rightarrow T \leftarrow$  (to scroll backwards) until one finds the "tArE t" parameter.
  - Press  $\downarrow$  to enter the parameter.
  - With the  $\rightarrow 0 \leftarrow$  or  $\rightarrow T \leftarrow$  keys select the possible options: "LoCK" (locked tare), "unLoCK" (unlocked tare), diSAb (disabled tare).
  - Confirm with  $\downarrow$
  - Press the C key many times until the display shows the message "SAVE?".
- Press  $\downarrow$  to confirm the changes made or another key for not saving.

## 7 SELECTABLE OPERATING MODES

In addition to the STANDARD weighing mode with TARE deduction and transmission of data, the indicator can carry out one of the following functions:

kg/lb CONVERSION, NET/GROSS SWITCH, SET POINT ON THE GROSS WEIGHT, SET POINT ON THE NET WEIGHT, IN/OUT, ALIBI, DISPLAY WITH SENSITIVITY X 10, HOLD THE DISPLAY, PEAK, HORIZONTAL TOTALIZER, VERTICAL TOTALIZER, and PIECE COUNTING.



To set the operating mode, carry out the following procedures:

- Turn on the unit, after 07.XX are displayed, press the  $\rightarrow T \leftarrow$  (the display shows the tYPE menu).
- Press  $\rightarrow 0 \leftarrow$ , the display shows F.MoDE, press  $\downarrow$ , the display shows FunCt.
- Press  $\downarrow$  to enter the parameter.
- With the  $\rightarrow 0 \leftarrow$  or  $\rightarrow T \leftarrow$  keys select the possible options:

- Std** kg / lb conversion
- ntGS** net weight / gross weight conversion
- inout** Input / output weighing (please refer to user manual 2/2)
- ALibi** memory Alibi / DSD (option, please refer to user manual 2/2)
- UiSS** Sensitivity (x10)
- hLd** Hold (please refer to user manual 2/2)
- PEAK** Peak detector (please refer to user manual 2/2)
- tot o** Horizontal totalizer (please refer to user manual 2/2)

**tot S** Vertical totalizer (please refer to user manual 2/2)  
**Coun** Counting (please refer to user manual 2/2)

- Confirm with  $\downarrow$  if one has selected the inout, tot or, tot S or Coun mode, one will be asked to select another operating parameter; refer to the specific functioning mode section for the relative description.
- Once the functioning mode is selected, one is asked to enable the standard printouts: the "dEF.Pr?" message appears on the display: press  $\downarrow$  to enable the printouts and C to exit without making any modifications.
- The instrument automatically goes to the following step.
- Press many times the C key until the display shows the message "SAVE?".
- Press  $\downarrow$  to confirm the changes made or another key to not save.

### 7.1 kg/lb CONVERSION (Std)

By pressing "MODE" key the value is converted from kg to lb and vice versa.

#### NOTES:

- with APPROVED instrument in single range the weight in pounds is displayed for 5 seconds, after which the display goes to kilograms. During the viewing in pounds it is not possible to print the weight (when pressing  $\downarrow$  the message "ConV" is shown and an acoustic signal is emitted).

### 7.2 NET/GROSS SWITCH (ntgS)

If a tare is set by pressing the MODE key, for about 3 second interval, the gross weight is displayed.

**NOTE:** While the gross weight is being viewed it is not possible to print.

### 7.3 DISPLAY WITH SENSITIVITY X 10 (UISS) (TO BE USED IN TESTING DURING THE CALIBRATION)


By pressing the MODE key one switches from the weight display with normal sensitivity to a sensitivity ten times greater; in fact, one will note that the last digit on the right of the display will have a sensitivity equal to the scale's division divided by 10.

If a printout is carried out, the weight values are printed with the normal sensitivity.

### 7.4 SETPOINTS (static relays)

The IPE50 unit is available with 2 setpoints (6 setpoints in option with IPE50 Panel).

In the menu output, you must select for each relay the mode of functioning, the status of the contact, with or without hysteresis .....



**Func :** Functioning mode of the 2 setpoints (available for setpoint 1 to 6)

**0 nonE :** the setpoint is disable

**1 GroS** : setpoint on the gross display  
**2 nEt** : setpoint on the net display  
**3 PCS** : setpoint on the counting mode  
**4 Gro.O** : the setpoint will be actionned when the display will be at 0 in gross value  
**5 nEt.O** : the setpoint will be auctioned when the display will be at 0 in net value  
**6 Moti.** : the setpoint will be actionned if the display is not stable (LED ~ on)  
**23 K.Pr** or **24 K.oK**: When you press the key "↵" the contact will be closed during approximatively 2 seconds  
**25 .K.Mod** : When you press the key "MODE" the contact will be closed during approximatively 2 seconds  
**26 K.C** : When you press the key "C" the contact will be closed during approximatively 2 seconds  
**27.K.Zer** : When you press the key "->0<-" the contact will be closed during approximatively 2 seconds  
**28.K.tAr** : When you press the key "->T<-" the contact will be closed during approximatively 2 seconds  
**29 .Err** : the setpoint will be on if the display shows the message \_ \_ \_ \_ \_ (overload) or - - - - - (underload)

**OUT.1, OUT.2 .... OUT.6** : selection of setpoint 1 or 2 (more than 2 depends of the IPE50P version) for programmation of the parameters

**no/nC** : no normally opened or nC normally closed

**onStAt** : **drCt** the relay could change if the display is unstable / **StbL** the relay could not change if the display is stable (LED ~ off)

**rL.iSt**: selection without **iSt.oFF** or with **iSt.on** hysteresis

**EnAb.tM** : Select a time (from 0.0 to 100.0 seconds) that the relays will be on (if the display is upper than the setpoint value), after this time, the relay will switch off (even the display is upper than the setpoint value).

The value 0.0 disable this function.

**DELAY** : Select a time (from 0.0 to 100.0 seconds) of delay that the relays could not be on (even the display is upper than the setpoint value) after this delay, le relay could be on (if the display is upper than the setpoint value).

The value 0.0 disable this function

**SiGN** : the setpoint will be operating with only a positive value on the display (PoSit) or only with a negative value (nEGAt). The step will be showed only if the function of the setpoint is 2 nET.

## 7.5 Adjustment the setpoint value

### MODE WITH HYSTERESIS

One enters two SET POINTS for each relay: a DISABLING one, which, when the gross weight is lower than it, it disables the concerned relay; and an ENABLING one, which, when the gross weight is equal or greater than it, it enables the concerned relay.

**By keeping the ↵ key pressed for about 3 seconds**, one enters the DISABLING and ENABLING SET POINT values, only for the configured relays:


- The display shows " S1 on " (enable relay 1 SET POINT): press ↵ to enter the Step.
- Use the MODE key to choose the digit to be increased (BLINKING DIGIT), the scrolling of the digits goes from left to right.
- Decrease or increase the value using the ->0<- or ->T<- keys.
- When finished entering the values, confirm with ↵
- The display shows " S1 oFF " (disable relay 1 SET POINT): enter the weight value like in the preceding SET POINT and confirm with ↵ , with the C key, one quickly zeros the set point value.
- In the same way go ahead with the "Sb2.on", "Sb2.oFF",.
- Once finished the programming of the set points, one should exit with the C key to return to weighing.

### NOTES

The 0 value is valid for the enabling and the disabling set points and just the setpoints greater or equal to zero are accepted.

- The setpoint value is entered without sign ( + or -)
- If the relay functioning mode has not been configured, the prolonged pressure of the ↵ key has no effect.

- The DISABLING SET POINT must be equal or less than the ENABLING one;  
If in the DISABLING SET POINT one enters and confirms a value greater than the ENABLING one, the instrument will automatically set 0 value and wait for a correct value.  
If in the ENABLING SET POINT one enters and confirms a value greater than the max capacity, the instrument will automatically set 0 value and wait for a correct value.
- The check of the weight remains active on the present value even during the modification of the SET POINT, until the new value is confirmed.
- At start-up, the relays are managed from when the software version is displayed and these take on the configuration set in the set-up environment. These are not managed inside the set-up menu.
- The tare operations are active.



#### MODE WITHOUT HYSTERESIS

It is the same as the functioning mode with hysteresis, except that one enters just one SETPOINT value S.1 on and S.2 on (therefore the enabling threshold coincides with the disabling threshold).

### 7.6 INPUT CONFIGURATION (for the 2 inputs remote control)

In this step one sets the function to link to each input on the screw terminal

<b>nonE</b>	Disabled
<b>ZErO</b>	->0<- Key
<b>tArE</b>	->T<- Key
<b>ModE</b>	MODE Key
<b>Print</b>	↵ Key
<b>C</b>	C Key
<b>oFF</b>	Put the IPE50 in standby (display off)
<b>diS.kEy</b>	DISABLING OF KEYBOARD
<b>(!) nonE</b>	


#### Note:


If you select the parameter **diS.kEy**, the second input will be disabled and the keys of the unit too.

## 8 INSTRUMENT MESSAGES WHILE IN USE

MESSAGE	DESCRIPTION
- - - - -	Message is displayed when the display is higher than the max capacity programmed in calibration mode
.....	Message displayed when the display is lower than the zero memorized in calibration mode
AL. Err	In Alibi mode, when you switch on the unit, the unit detects a problem with the alibi card, check that there is a alibi card inside the unit
BuSy	Print under way (PRN serial port is occupied) or indicator waiting to transmit a printing to a PC.
UnStAB	One is trying to print with an unstable weight.
un.oVEr	One is trying to print with the weight in underload or in overload, in other words, with a weight of 9 divisions greater than the capacity or of 20 divisions below the gross zero.
GroS.Er	One is trying to print with a not positive gross weight (equal or less than zero).
Net.Err	One is trying to print with a not positive net weight (equal or less than zero).
LoW	Net weight less than the minimum weight provided for the printing or the totalisation.
no.0.unS	Weight not passed by net 0 or by instability.
ConV.	In standard mode, with approved instrument, one is trying to print while the instrument is converting the unit of measure.
no in	In the input/output mode (set as "in.out"), one is trying to acquire a second time the input weight.
no out	In the input/output mode (set as "in.out"), one is trying to acquire a second time the output weight.
no 1	In the input/output mode (set as "G.t." or "1st.2nd"), one is trying to acquire a second time the input weight.
no 2	In the input/output mode (set as "G.t." or "1st.2nd"), one is trying to acquire a second time the output weight.
Er.Mot	In the counting mode, the sampling has not been made because the weight is unstable.
Error	In the counting mode, the sampling has not been made because one should use a higher reference quantity.
oVEr	The nput signal is too high (maximum : $\pm 30\text{mV}$ )

# 9 BLOCK DIAGRAM





----- SERIAL

Serial connection  
for PC, printer....

**See user manual 2/2**

You can download it on our website  
[www.800loadcel.com](http://www.800loadcel.com)

## DESCRIPTION OF THE STEPS

### TYPE

**Ind.Ch.** Standard using for 1 to 4 independent channels (selection of the channel displayed, press the key "MODE" 3 sec then select the channel with key "->T<-" and validation with key "↵")

**DEP.Ch.** Using for the connection of 2 to 4 identical sensors on a same system

**TrAnSM.** same as for ind.Ch, except that the keys, the zero tracking and the autozero at the start-up are disabled and it is possible with one serial command, to receive the values of all the activated channels .

### F.Mode

#### FunCt FUNCTIONING MODE

<b>Std</b>	Kg / lb conversion.
<b>ntGS</b>	Net weight / gross weight conversion.
<b>inout</b>	Input / output weigh.
<b>ALibi</b>	Not available
<b>UiSS</b>	Sensitivity times ten.
<b>hLd</b>	Hold.
<b>PEAK</b>	Peak detector.
<b>tot o</b>	Horizontal totalizer.
<b>tot S</b>	Vertical totalizer.
<b>Coun</b>	Counting.

**NOTE:** If one has selected the "inout", "tot o", "tot S" or "Coun" mode one will be asked to also select a functioning parameter: see the functioning mode section for the relative description.

Once the functioning mode has been selected, one is asked to enable the standard printouts of that mode; the display shows the message "dEF.Pr?": press ↵ to enable the printouts, or C to enable just the functioning mode and not the relative printouts.

(!) Std

#### Scr.SAv: SCREEN SAVER

If the indicator has the date/time option, it is possible to enable the "Screen Saver" function: after a programmable time (from 1 to 255 minutes) that the scale is unloaded, the time is shown on the display, in the "HH-MM.SS" format. As soon as a weight variation is detected, or a key is pressed, the indicator displays the current weight once again.

**no** Disabled.

**yES** Enabled: one is asked to enter the time which the indicator waits to activate the screen saver, after the weight has become stable and keys are not pressed.

(!) no

#### irConF: remote control configuration (IPE50 XLI only)

**ir no** remote control disable

**ir 1** all the remote control keys work as the TARE key

**ir 4** the remote control keys work as ZERO, TARE, MODE and ENTER/PRINT

(!) ir no

#### rEACt REENABLING OF THE PRINTOUTS AND THE INDICATOR FUNCTIONS

While using the indicator, it is possible to incur in the "no.0.unS" error shown on the display accompanied by an acoustic signal; this means that the printout or the function which one wants to carry out must be reenabled (in order to avoid accidental executions).

It is possible to set the reenabling in the following modes: "passage of the net weight by zero", "weigh

instability" or "always".

**Z**ero passage of the net weight by zero

**i**nSt instability

**ALW**AYS always

(!) **Z**ero

### **L.int** DISPLAY INTENSITY (IPE50 XLI only)

Lint 1 (minimum) to Lint 4 (maximum)

(!) **L**int1

### **C**LoCK DATE/TIME ADJUSTMENT (OPTIONAL)

In this step one sets the date and time of the indicator; by pressing ↵ one is asked to enter, in this order, the day, month, year, hour and minute.

The entry of each parameter must be confirmed with ↵

**NOTE:** the parameter is not displayed if there is no date/time option.

### **tArE t** LOCKED / UNLOCKED / DISABLED TARE SELECTION

**Lo**CK locked tare

**unLo**CK unlocked tare

**di**SAb disabled tare

See the "TARE OPERATIONS" section for further functioning details

(!) **Lo**CK

### **Auto**FF AUTO SWITCH-OFF

It is possible to enable the automatic switch off of the indicator (from 1 to 255 minutes), or disable it; the auto switch-off starts working when, **with unloaded scale**, the weight has not been moved or a key has not been pressed during the set time: the display shows the blinking "- oFF - " message then the indicator turns off.

**Di** SAb auto switch-off disabled.

**En**Ab auto switch-off enabled (one will be asked to enter the number of minutes after which the indicator must turn off: enter a number from 1 to 255).

(!) **di** SAb

## 10 **SEtUP** SCALE CONFIGURATION

### **Con**FiG (configuration)

**Fi**Lt.50 cutoff band filter 50Hz

You can enable (yes) or disable (no) a cut-off band at 50Hz

(!) **no**

### **Param.** PARAMETERS

#### **StAbi**L FILTERING INTEGRATION

By pressing the ↵ key one accesses the selection of the type and degree of filter intervention for the stability of the weight indication:

<b>FL</b> t	0 to 3	filter for simple weighing
<b>FF</b> .50	1 to 3	filter for dosage 50 measurements/second
<b>FF</b> .100	1 to 4	filter for dosage 100 measurements/second
<b>FF</b> .200	1 to 3	filter for dosage 200 measurements/second
<b>h.r.</b>	0 to 7	filter very slow for high resolution
<b>dYn.</b>	0 to 3	filter for crane scale

FF. 400 can be used only in transmission mode via RS port

Custom reserved for factory, don't use it

The higher the filter value is, and greater is its intervention relative to the type of filter used.

### (!) Flt 3

Note: the filter FF.200 is not suitable in the mode **DEP.Ch.** for 3 or 4 channels

### Auto-0 AUTOZERO AT THE START UP

By pressing  $\downarrow$  one chooses whether to enable (EnAb) or disable (diSAb) the automatic acquisition of the gross zero upon start-up. By choosing EnAb, if upon start-up a detected weight is within +/- XX% of the capacity (value set in rAnGE 1), it is zeroed; if the weight is not within this tolerance, the non approved instrument's display will show the present weight after a few instants, while an approved instrument will continuously show "ZEro" on the display, until a weight within tolerance is placed.

If you choose EnAb, the step C.PerC will be displayed, press  $\downarrow$ , you can choose a number from 1 to 50 (1 to 10 in trade approval mode), value in percentage of the capacity.

### (!) EnAb -50 (2 in trade approval mode)

### (\*) 0-PErC key ->0<-

You can change the percentage of the function of the key ->0<- from 0 (the key is disabled) and 50% (in trade approval mode 2% max). This value is a percentage of the max capacity set in ConFIG -> CALIB -> RAnGE1.

Ex: RAnGE1 = 500.0 and 0-PerC set at 20 -> 20% of 500.0 = 100.0, if the weight is higher than 100.0, the key is not operating.

### (!) 50 (2 in trade approval mode)

### (\*) 0trACk ZERO TRACKING

This menu allows setting the zero tracking, in other words, the compensation parameter of the scale's thermal drift; the set value corresponds to the number of divisions that is reset in the fixed time of 1 second.

tr. ½ +/- half division.

tr. ¼ +/- one fourth of a division

tr. 1 +/- one division.

tr. 2 +/- two divisions.

tr. no tracking disabled.

**NOTE: If the indicator is approved, the step may not be modified.**

### (!) tr. ½

### diU.Stb DIVISIONS BY STABILITY

In this step one enters the number of divisions by which the instrument detects the weight stability; the higher the number of divisions, less is the sensitivity, and consequently the stability is more easily detected. The possible values are 1...19.

**NOTE: with approved instrument, it is possible to enter just the values 1 or 2; if one enters a higher value, it will be confirmed, but when returning to the step, the last stored value (acceptable) is re-proposed.**

### (!) 5

### (\*) GrAV GRAVITY ZONE AND ZONE OF USE

Through this step one selects the gravity zone **of calibration and of use** of the instrument.

One may manually enter the gravitational acceleration value; **one must modify just the 5 decimal digits of the gravitational acceleration.**

In case one enters a wrong g value, the minimum decimal value is suggested (9,75001); a wrong value is any decimal number that is not between 9,75001 and 9,84999 (inclusive).

**NOTE: If the indicator is approved, the step can not be modified.**

### (!) 9.80655

### (\*) CALib. SCALE CALIBRATION / ADJUSTMENT

See paragraph "ADJUSTMENT" section.

### (\*) 0CALib. QUICK ZERO CALIBRATION / ADJUSTMENT

See paragraph "CALIBRATION" section.

**NOTE: If the indicator is approved, the step is not displayed.**

## Serial (SERIALS, PRINTOUTS, ETC...)

Please refer to user manual 2/2

### dSP.rF

norm (keep this parameter)

1 h2, 2.5 h2, 5 h2, 10 h2, 20 h2

(!) norm

### dSALE Do not enter in this step

(!) no

### inPutS INPUT CONFIGURATION

In this step one sets the function to link to each input

#### inP.b1 INPUT 1

nonE Disabled

ZErO ->0<- Key

tArE ->T<- Key

ModE MODE Key

EntEr ↵ Key

diS.kEy DISABLING OF KEYBOARD

(!) nonE

#### inP.b2: INPUT 2

The programming of the inputs 2 is done as described for input 1.

**NOTE: In case 2 inputs are simultaneously enabled with the same function, just the input 1 is taken into consideration.**

### outPut RELAY CONFIGURATION

In this step one sets the function to be linked to each relay

**NOTE: the parameter is displayed only if the setpoint parameters has been selected**

#### rEL. 1 Relay 1

**FunC :** Functioning mode of the 2 setpoints (available for setpoint 1 and 2)

**0 nonE :** the setpoint is disabled

**1 GroS :** setpoint on the gross display

**2 nEt :** setpoint on the net display

**3 PCS :** setpoint on the counting mode

**4 Gro.O :** the setpoint will be actionned when the display will be at 0 in gross value

**5 nEt.O :** the setpoint will be actionned when the display will be at 0 in net value

**6 Moti. :** the setpoint will be actionned if the display is not stable (LED ~ on)

**23 K.Pr or 24 K.oK:** When you press the key "↵" the contact will be closed during approximately 2 seconds

**25 K.Mod :** When you press the key "MODE" the contact will be closed during approximately 2 seconds

**26 K.C :** When you press the key "C" the contact will be closed during approximately 2 seconds

27 **K.Zer** : When you press the key "->0<-" the contact will be closed during approximately 2 seconds

28 **K.tAr** : When you press the key "->T<-" the contact will be closed during approximately 2 seconds

29 **Err** : the setpoint will be on if the display shows the message \_ \_ \_ \_ \_ (overload) or - - - - - (underload)

**rEL.1** to **rEL.6** : selection of setpoint 1 or 6 for programming of the parameters (6 relays in option for IPE50 Panel only)

**no/nC** : **no** normally opened or **nC** normally closed

**onStAt** : **drCt** the relay could change if the display is unstable or **StbL** the relay could not change if the display is unstable (LED ~ off)

**rL.iSt**: selection without **iSt.oFF** or with **iSt.on** hysteresis

**EnAb.tM** : Select a time (from 0.0 to 100.0 seconds) that the relays will be on (if the display is upper than the setpoint value), after this time, the relay will switch off (even the display is upper than the setpoint value).

The value 0.0 disable this function.

**(!) 0.0**

**DELAY** : Select a time (from 0.0 to 100.0 seconds) of delay that the relays could not be on (even the display is upper than the setpoint value) after this delay, the relay could be on (if the display is upper than the setpoint value).

The value 0.0 disable this function

**(!) 0.0**

The same configurations are valid for:

**rEL.b.2** RELAY 2

## **An.out** ANALOG OUTPUT

<b>MODE</b>	Ao no the analog output is disable Ao nEt the analog output is enable and on the net value of the display Ao Gro the analog output is enable and on the gross value of the display
<b>Ao MAH</b>	Adjustment of the maximum signal (ex: 10V , 20mA..)
<b>Ao Zer</b>	Adjustment of the signal for the display is equal at 0
<b>Ao Min</b>	Adjustment of the minimum signal (ex: 0V, 4mA...)
<b>SiGn</b>	PoSit the output will function only on the positif display nEGAt the output will function only on the negatif display

Note: adjustment of the analog output chapter 13

## **dEFAu** INITIALIZATION OF THE UNIT

Through this step one can initialize the instrument with the subsequent activation of the default parameters. By pressing ↵, a confirmation message ("dFLt?") will appear: confirm again with ↵ or exit with any other key.

**NOTE: The initialization of the instrument causes a cancellation of the present calibration and the activation of the default parameters. In any case if one exits the setup environment WITHOUT CONFIRMING the modification made, all the parameters of the last saving made will remain (including the calibration).**

## **InI.AL** INITIALIZATION ALIBI/DSD MEMORY (option)

Initialization and reset the alibi/DSD memory if installed

## **DiAG** (DIAGNOSICS MENU)

It is a submenu inside which it is possible to check the software components and the scale hardware.

## **PrG.Uer** CHECKING THE SOFTWARE VERSION

By pressing ↵ the instrument shows the software version in the XX.YY.ZZ. format.

## **diV.int** CALIBRATION INTERNAL DIVISIONS OF CALIBRATION

By pressing  $\downarrow$  the instrument shows the calibration internal divisions when the unit has been adjusted. Press "C" to exit this step.

## **AdC.uU** MICROVOLTS

By pressing  $\downarrow$  the instrument shows the output signal of the loadcell (in microvolts) relative to the weight on the sensor.

If more than 1 channel are activated, if you press the key  $\rightarrow T \leftarrow$  or  $\rightarrow 0 \leftarrow$ , you could select one of the channel (Ch1 to 4), in the mode dEP.Ch it is also possible to see the SuM of the channels

**Note:** The maximum voltage that the instrument accepts in input is 30 mV (30000  $\mu V$ ); the weighing system is powered by the indicator at 5 VDC.

A correct operation will have a value less than 30000 with a weight of full scale capacity on the weighing system.

Press C key to exit this step.

## **AdC.MVV** SENSITIVITY

By pressing  $\downarrow$  the instrument shows the signal of the loadcells in mV/V corresponding at the weight on the system. ex: 1.00895

Press C key to exit this step.

## **AdC.Pnt** CONVERTER POINTS

By pressing  $\downarrow$  the instrument shows the A/D converter points relative to the weight on the scale.

If more than 1 channel are activated, if you press the key  $\rightarrow T \leftarrow$  or  $\rightarrow 0 \leftarrow$ , you could select one of the channel (Ch1 to 4), in the mode dEP.Ch it is also possible to see the SuM of the channels

If this number is higher than the display can show, the message h=1 to 5 is shown and after the value of converter points.

Press "C" to exit this step.

## **WEiGht** DISPLAY THE READING OF THE WEIGHT

By pressing  $\downarrow$  the instrument displays the reading of the weight.

Press "C" to exit this step.

## **CAL.PTS** DISPLAY THE DATA RECORDED WHEN THE CALIBRATION HAS BEEN DONE

By pressing  $\downarrow$  the instrument displays the values (converter points and display corresponding in alternation) that were stored during calibration. Visualization with the keys  $\uparrow$  or  $\downarrow$ . EX : 0.000 / 21468; 1.100 / 2147368

Press "C" to exit this step.

## **diSPLA** DISPLAY TEST

By pressing  $\downarrow$  the instrument turns on all the display segments one at a time, after which it exits automatically from the step.

## **KEYb.** KEYBOARD TEST

By pressing  $\downarrow$  the instrument displays 0000; by pressing the keys one at a time, the relative codes are shown to the display. One exits pressing the same key three times.

## **SEr** SERIALS TEST

By pressing  $\downarrow$  the instrument displays " S xy" in which x indicates the status of the printer serial port while y indicates the status of the PC serial port. Both can take on two values:

- 0 Serial port does not work
- 1 Serial port works

During the test one should short-circuit T/+ with R/- (in the PC terminal board) and TXD with RXD (in the PRN). Works only in RS232.

Furthermore the ASCII "TEST"<CRLF> string is continuously transmitted on both the serial lines.

### **CtS.St** TEST OF THE CTS STATUS

By pressing ↵ one views the status/level of the CTS signal of the printer (on) connected to the PRT serial port.

### **outPut** TEST OF THE I/O EXPANSION BOARD RELAYS

By pressing ↵ the instrument displays "rEL.1" and enables relay 1 of the expansion board; press the ->0<- or ->T<- key to enable this other relay of the connected expansion boards.

Press "C" to exit this step

### **InPutS** TEST OF THE I/O EXPANSION BOARD INPUTS

By pressing ↵ the instrument displays "i.bx-y" in which x, y indicate:

x – the input which is controlling 1, 2; to change the input which one wants to control press the ZERO or TARE keys.

y - the input status:

0 Disabled input

1 Enabled input

- communication error with I/O expansion board or board not present.

Press "C" to exit this step

### **Anout** ANALOG OUTPUT TEST

You could simulate a value of the analog output by modification of the value.

This value can be modified from 0 to 65535, valid by ↵ to simulate the output.

Press "C" to exit this step

Approximative values

Analog value (A/D)	output (V)	output (mA)
1200	0	0
12700		4
58600		20
62650	10	


**SER.nuM** : not used

# 11 ADJUSTMENT

**Note:** The manufacturer parameters of the IPE50 unit are: 2mV/V -> 10.000 per 0.001

Attention: the default calibration parameters will probably not match with your application requirements. You have to calibrate the system according to your needs.

Depending on the application, one can carry out two types of calibration: the one for the simple scale or the one for the pallet truck.



- >0<- Decreases the selected digit (blinking).
  - >T<- Increases the selected digit (blinking).
  - MODE Selects the digit to be modified (blinking), from left to right.
  - C Quickly zeros the displayed value.
- Valid the new value by pressing the key ↵.

- 1) Enter the SET-UP environment of the scale (when turned on, press the ->T<- key for an instant during the countdown).
- 2) TypE is displayed.  
Press ↵, ind.Ch. or DEP.Ch. or trAnSm. is displayed. With the key ->0<-, choose the functioning mode and press ↵ :  
**Ind.Ch.** Standard using for 1 to 4 independent channels  
**DEP.Ch.** Using for the connection of 2 to 4 identical sensors on a same system  
**TrAnSM.** . Same as ind.Ch, except that the keys, the zero tracking and the autozero at the startup are disable and it is possible with one serial command, to receive the values of all the channels operating.

## Type : TranSm

Same as ind.Ch, except that the keys, the zero tracking and the autozero at the startup are disable and it is possible with one serial command, to receive the values of all the channels operating.

## Type : ind.Ch. (for DEP.Ch. see paragraph after)

- 3) Select the **SEtuP** (with key ->T<- then ↵) → **ConFiG** (with key ↵) → **CALib** (with key ->T<-) and press ↵.
- 4) NChAn is displayed, press ↵ -> Ch x where x is the channel number which must be adjusted.  
(for 1 channel or 1 sensor, choose Ch 1 because the sensor must be connected in channel 1 (CELL1))
- 5) ParAM is shown, choose CALib with key ->0<- and press ↵.
- 6) Select the "dECI" step (decimal point) and press ↵  
The selectable values are 1.0 (a decimal), 1.00 (two decimals), 1.000 (three decimals), 100000 (no decimal); confirm with ↵  
**(!) 1.0**
- 7) Select the "u.M." step and press ↵  
Set the unit of measure (g, Lb, t, kg) and press ↵  
**(!) kg**
- 8) Select the "diU" step and press ↵  
Set the minimum division and press ↵ (selectable values: 1, 2, 5, 10, 20, 50).  
**(!) 1**
- 9) Select the "rAnGE1" step and press ↵;  
Set the total capacity of the scale or the first range in case of multirange functioning (ex: 002.000 it means maximal display of 2.000)  
Confirm with the ↵ key.
- 10) Select the "rAnGE2" (if the system is a simple range, SET this value to 0) and press ↵  
Set the capacity of the second range and press ↵
- 11) Select the "CALib.P" ,calibration steps, and press ↵
- 12) Select the "ntP" step and press ↵  
With the ->0<- or ->T<- keys set the number of points with which one wants to calibrate (from 1 to 3, with 1 it does the zero point and one weight point) and press ↵
- 13) Select the "tP0" (scale zero point) step and recording of the signal of the loadcell: unload the scale (position "0") and wait a few seconds, then press ↵, the unit will go automatically to the next step after recording the sensor signal.
- 14) Select the "ddt1" (setting first reference weight) step ; press ↵, enter the weight value that you are applying on the loadcell and confirm with ↵
- 15) Select the "tP1" (acquisition of first reference weight) step: put the weight (equal at the value on ddt1) on the loadcells, wait a few seconds and press ↵, the unit will go automatically to the next step after recording the sensor signal.

16) **If a calibration point has been set**, once the weight acquisition has been made, the display shows for an instant the value of the internal divisions and then the "nP" step.  
**If there are various calibration points, repeat the operations for the "ddt2", "tP2", "ddt3", "tP3" points.1**

17) Once the calibration has been made of all the necessary points, press the C key various times until the indicator shows "SAVE?" in the display: confirm with ↵ to memorize and return to weighing.

**N.B.:** the calibration points must be increasing (point 1 < point 2 < point 3).

### Type : dEP.Ch

- 3) Select the **SEtuP** (with key ->T<- then ↵) → **ConFiG** (with key ↵) → **CALib** (with key ->T<-) and press ↵.
- 4) NChAn is displayed, press ↵ -> Ch x where x is the channel number which must be adjusted.  
(for 1 channel or 1 sensor, choose Ch 1 because the sensor must be connected in channel 1 (CELL1))
- 5) ParAM is shown, choose CALib with key ->0<- and press ↵.

Calibration with load on the system, for theoretical calibration (with loadcell parameters, less accuracy) see paragraph 22)

- 6) Select the "dECI" step (decimal point) and press ↵  
The selectable values are 1.0 (a decimal), 1.00 (two decimals), 1.000 (three decimals), 100000 (no decimal); confirm with ↵  
**(!) 1.0**
- 7) Select the "u.M." step and press ↵  
Set the unit of measure (g, Lb, t, kg) and press ↵  
**(!) kg**
- 8) Select the "diU" step and press ↵  
Set the minimum division and press ↵ (selectable values: 1, 2, 5, 10, 20, 50).  
**(!) 1**
- 9) Select the "rAnGE1" step and press ↵;  
Set the total capacity of the scale or the first range in case of multirange functioning (ex: 002.000 it means maximum display of 2.000)  
Confirm with the ↵ key.
- 10) Select the "rAnGE2" (if the system is a simple range, SET this value to 0) and press ↵  
Set the capacity of the second range and press ↵
- 11) Select the "CALib.P" ,calibration steps, and press ↵
- 12) EquAL is displayed, it is used to "off-center adjustments" (corners adjustment of the load receptor)  
Go to the step 16 by pressing the key ->0<- many times if you don't want to do this adjustment.
- 13) Eq0 is displayed, the load receptor must be at zero (without load), the unit will memorize the signal of the load cells, press ↵. Eq0 blinks and after the unit will pass at the next step automatically.
- 14) Eq1 is displayed to indicate the adjustment of the loadcell which is connected to the channel 1.  
Apply the load on loading point 1 (over loadcell 1) and press ↵.

Eq1 blinks and after the unit will pass at the next step automatically.

- 15) Eq2 is displayed to indicate the adjustment of the loadcell which is connected to the channel 2.  
Apply the load on loading point 2 (over loadcell 2) and press ↵.  
Eq2 blinks and after the unit will pass at the next step automatically.  
Do the same for loadcell 3 or 4 if the channel 3 or 4 are connected to the loadcells.  
When all the adjustments will be finished, the message Eq OK will display to indicate that the adjustment are finished and OK.
- 16) Select the "ntP" step and press ↵  
With the ->0<- or ->T<- keys set the number of points with which one wants to calibrate (from 1 to 3, with 1 it does the zero point and one weight point) and press ↵
- 17) Select the "tP0" (scale zero point) step and recording of the signal of the loadcell: unload the scale (position "0") and wait a few seconds, then press ↵, the unit will go automatically to the next step after recording the sensor signal.
- 18) Select the "ddt1" (setting first reference weight) step ; press ↵, enter the weight value that you are applying on the loadcell and confirm with ↵
- 19) Select the "tP1" (acquisition of first reference weight) step: put the weight (equal at the value on ddt1) on the loadcells, wait a few seconds and press ↵, the unit will go automatically to the next step after recording the sensor signal.
- 20) **If a calibration point has been set**, once the weight acquisition has been made, the display shows for an instant the value of the internal divisions and then the "ntP" step.  
**If there are various calibration points, repeat the operations for the "ddt2", "tP2", "ddt3", "tP3" points.1**
- 21) Once the calibration has been made of all the necessary points, press the C key various times until the indicator shows "SAVE?" in the display: confirm with ↵ to memorize and return to weighing.  
**N.B.:** the calibration points must be increasing (point 1 < point 2 < point 3).
- 22) Theoretical calibration. Press the key ->0<- twice, "thEo.CA" is displayed, press ↵.  
Attention, this type of calibration is less accuracy than with real load on the system.
- 23) CEL.SEn , (signal in mV/V of one or many loadcells connected) press ↵. Enter the signal value of one or many loadcells corresponding at the value which will be setting in the step CEL.CAP, attention if many loadcell are connected to the IPE50.  
Ex : 1 loadcell of 10t with signal of 2mV/V, you enter 2mV/V for 10t in step CEL.CAP  
Ex : 3 loadcells of 10t with signal of 2mV/V, you enter 2mV/V for 3x10t = 30t in step CEL.CAP  
Press ↵
- 24) CEL.CAP, (range of one or many loadcells connected) press ↵. Enter the range of one or many loadcells corresponding to the value entered in step CEL.Sen attention if many loadcell are connected to the IPE50.  
Ex : 1 loadcell of 10t with signal of 2mV/V, you enter 10t for 2mV/V in step CEL.SEn  
Ex : 3 loadcells of 10t with signal of 2mV/V, you enter 3x10= 30t for 2mV/V in step CEL.SEn  
Press ↵
- 25) DEAd.Id (dead load)  
If you want to enter the value of the system dead load (empty silo weight for ex) press ↵ in other case press ->0<- (kno.WGt is displayed see paragraph after)  
You could enter the weight dead load value with the keys

If no number after the coma has been selected, you could set value from -99999.9 to 99999.9  
If 1 number after the coma has been selected, you could set value from -9999.99 to 9999.99  
If 2 numbers after the coma has been selected, you could set value from -999.999 to 999.999  
If 3 numbers after the coma has been selected, you could set value from -99.9999 to 99.9999  
Press ↵

Or

26) Kno.WGt (enter the value of the know weight on the system) in another case press the ->0<-  
(CEL.Sen is displayed, press key C, th.CAL? is displayed, press ↵ to memorize, rAnGE1 is displayed,  
see paragraph 23).

If the system is loaded with a know weight, you can set the unit with this weight (with the keys). The  
unit will memorize the loadcells signal and the weight Press ↵, GET.Wt? is displayed, press ↵.  
Enter the weight that you want that the unit displays.

Wait is displayed for several seconds (the unit memorize the loadcells signal) then Kno.WGt is blinking  
and after the unit will go to the step CEN.Sen, press C, th.CAL? is displayed, press ↵, rAnGE1 is  
displayed.

27) Press the C key various times until the indicator shows "SAVE?" in the display:  
Confirm with ↵ to memorize and return to weighing.

## QUICK CALIBRATION OF ZERO

It is useful to calibrate just the point of ZERO when a permanent tare weight is put onto the platform (for  
example a roller unit).

- 1) Enter in the SET-UP environment of the scale (when turned on, press for an instant the TARE key).
- 2) Enter in the **SEtuP** → **ConFiG** → **0.CALib** step and press ↵ key (the display shows "CAL.0?").
- 3) Put the tare on the scale and press ↵ key to confirm the operation.
- 4) Once the zero calibration is made, press many times the C key until the indicator shows "SAVE?" in the  
display: confirm with ↵ to store and return to weighing.


## 12 ANALOG OUTPUT

This IPE50 has an analog output (0/10V or/and 4/20mA) which is automatically calibrated for the higher value (10V or 20mA) of the max capacity selected in rAnGE 1. These outputs correspond to the displayed value.

You must adjust this output through the step AoMAX and AoZEr (see step after)

It works only on a positive display if the step SiGn = PoSit (if the display is negative, the output will be the minimum value set at Ao ZEr step), It works only on a negative display if the step SiGn = nEGAt (if the display is positive, the output will be the minimum value set Ao ZEr step).

It is possible to modify these adjustments in the step : An.out



**MODE**      **Ao no** the analog output is disable  
**Ao nEt** the analog output is enable on the net value of the display  
**Ao Gro** the analog output is enable on the gross value of the display

**Ao MAH**      Adjustment of the maximum signal press key ↵  
 You can adjust the maximum value of the signal for the maximum display. The value must be set between 0 and 65535 (see chart below).  
 You can modify the value with the arrow keys and confirm with ↵ key.

**Ao ZEr**      Adjustment of the signal for the display is equal at 0  
 You can adjust the minimum value of the signal for the 0 display. The value must be set between 0 and 65535 (see chart below).  
 You can modify the value with the arrow keys and confirm with ↵ key.

**Ao Min**      Adjustment of the minimum signal (ex: 0V, 4mA...)  
 You can adjust the minimum value of the signal. The value must be set between 0 and 65535 (see chart below).  
 You can modify the value with the arrow keys and confirm with ↵ key.

**SiGn** (only if Ao nEt is selected)  
 PoSit the output will function only on the positif display  
 nEGAt the output will function only on the negatif display

### APPROXIMATE VALUES BETWEEN THE D/A CONVERTER AND ANALOG OUTPUT

D/A CONVERTER VALUES	VOLTAGE VALUE (V)	CURRENT VALUE (mA)
1200	0	0
12700		4
58600		20
62650	10	

## 13 ERROR MESSAGES

While using the indicator, it is possible to incur in the following errors:

MESSAGE	DESCRIPTION
ADC Err	Analog/digital convertor doesn't work. Check the wiring of the loadcells. Measure the signal output of the loadcells between the pins + and - sig, the tension must not exceed 15mV.
PREC.	It is displayed if one tries to calibrate a point without first having confirmed the number of calibration points
ERMOT	Weight unstable during the acquisition of a point during calibration.
ERPNT	During the acquisition of a calibration point a null value has been read by the converter.
Er - 11	Calibration error: a too small sample weight has been used; it is advisable to use a weight equal to at least half of the scale capacity.
Er - 12	Calibration error: the acquired calibration point (tP1 or tP2 or tP3) is equal to the zero point (tP0).
Er - 37	The converter points are less than the instrument's internal divisions. The sensor signal is negative The load has not been applied on the step TP1
Er - 39, No CAL	It is displayed when the instrument has not yet been calibrated and initialized. Press the ->T<- key when the instrument displays "ERR - 39" to enter the technical set-up environment (with the standard procedure it is not possible) programming of all the parameters of the set-up environment and the calibration.
C.Er.-36	During the calibration some internal negative points have been calculated: - the calibration point is less than the zero point - the signal is negative (check the connections)
C.Er.-37	During the calibration some internal points less than the minimum value have been calculated: - The calibration point is equal to the zero point - A capacity too high in relation to the division has been set
HW-Err	Hardware error. Software not compatible with the installed hardware. The hardware expansion is missing which allows the software to function.

## 14 ELECTRICAL CONNECTION

See user manual "short guide"

NU-IPE50-1-E-0313